## POWER[WINDOW[CONTROL[\$YSTEM

	0563J-01
HOW[TO[PROCEED[WITH[TROUBLESHOOTING	
Troubleshoot[in[accordance[with[i]he[procedure[on[i]he[i]ollowing[pages.	
1 VEHICLE BROUGHT IN	
2 CUSTOMER[PROBLEM[ANALYSIS[CHECK[AND[SYMPTOM[CHECK (See[page[05-1152])]	
3 PROBLEM[\$YMPTOMS[TABLE[(See[page[05-1155])]	
(a) [] \A/ithau than line black was to see the condition (A)	
(a) Without[applicable[symptoms,[proceed[do]A".  (b) With[applicable[symptoms,[proceed[do]B".	
B  Go  Go  Go  Go  Go  Go  Go  Go  Go  G	
A	
4 PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON	
MALFUNCTION[\$YMPTOM	
(a) On-vehicle nspection See page 70-1).	
(b) Inspection See page 70-2)	
(c) Terminals of ECU See page 5-1154).	
5 ADJUSTMENT, REPAIR OR REPLACEMENT	
END	