055VP-02

## DIAGNOSTIC TROUBLE CODE CHART

DTC[No. (Door[φpen indicator)	Diagnostic⊡tem	Diagnostic∏esult
49 (See page 05-1283)	Double lock control ECU communication stop	No communication from theft double lock control ECU more than 10 seconds.