HOW TO PROCEED WITH TROUBLESHOOTING

05256-29

The hand-held tester can be used in steps 4, 6, 8 and 9. VEHICLE BROUGHT TO WORKSHOP NEXT 2 CUSTOMER PROBLEM ANALYSIS (SEE PAGE 05-1451) NEXT 3 WARNING LIGHT CHECK (SEE PAGE 05-1456) NEXT DTCs CHECK (Present and Past DTCs) (SEE PAGE 05-1464) DTCs ARE OUTPUT (INCLUDING NORMAL SYS-TEM CODE): Go to step 5 DTCs ARE NOT OUTPUT: PROBLEM SYMP-TOMS TABLE (SEE PAGE 05-1477) 5 DTCs CHART (SEE PAGE 05-1478) NEXT CIRCUIT INSPECTION (SEE PAGE 05-1483 TO 05-1773) 6 NEXT 7 **REPAIR** NEXT CLEAR DTCs (Present and Past DTCs) (SEE PAGE 05-1464) NEXT DTCs CHECK (Present and Past DTCs) (SEE PAGE 05-1464) DTCs ARE NOT OUTPUT: Go to step 10 DTCs ARE OUTPUT: Go to step 5

10	SYMPTOM SIMULATION (SEE PAGE 01-22)
	WARNING LIGHT REMAINS OFF: Go to step 11
	WARNING LIGHT IS ON: Go to step 5
11	CONFIRMATION TEST
NEXT	
END	