
05FJ0-01


NAVIGATION CHECK MODE PARTS INFORMATION)

HINT:


- This mode displays product information on the dadio and havigation assy and discs.
- Illustrations[may[differ[from[]]]he[actual[]]yehicle[depending[]]on[]]he[device[settings[]]and[]]ptions.[Therefore,[some[]]detailed[]]areas[]may[]]hot[]]be[]shown[]]exactly[]]he[]]he[]actual[]]yehicle.
- 1. Enter diagnostic mode (see page 05-39).



2. Select "Navigation Check" from the "Diagnosis MENU" screen.



3. Select "Parts Information" from the "Navigation Check" screen.



4. Check the navigation and disc information when the "Parts Information" screen is displayed.

Display	Contents
Navigation Manufacturer/*1	Radio and navigation assy manufacturer name is displayed.
Navigation Version/*2	Radio and navigation assy version is displayed.
Disc Manufacturer/*3	Map disc manufacturer is displayed.
Disc Version/*4	Map disc version is displayed.