■SYSTEM OPERATION

The Body ECU performs the following functions and system controls described in the chart.

Function		Body	Body ECU	
		LHD	RHD	
Interior Light	Illuminated entry system control	0	0	
Exterior Light	Light Auto turn-off system control	0	0	
	Daytime running light system control*1	0	_	
	Automatic light control system	0	0	
Warning Control	Key reminder warning	0	0	
	Door ajar warning	0	0	
Door Lock Control	Door lock control switch manual operation	0	0	
	Key-linked lock and unlock function	0	0	
	Manual unlock prohibition function	0	0	
	Key confine prevention function	0	0	
Wireless Door Lock Remote Control System	Door lock and unlock operation	0	0	
	Answer back operation	0	0	
	Luggage door open operation	0	0	
Double Locking System	Double Lock Request	_	O*2	
Diagnosis	Self diagnosis	0	0	

^{*1:} Optional Equipment
*2: Only for The European Models