
REAR COMBINATION LAMP LENS LH REPLACEMENT

650C9-01



1. REMOVE REAR COMBINATION LAMP LENS LH

- (a) Remove the service hole cover.
- (b) Remove the 3 nuts and disconnect the connector of rear combination light.
- (c) Pull the rear combination light assy to the back of the vehicle, and remove the rear combination light assy.