
## LUGGAGE COMPARTMENT OPENING TROUGH (ASSY) REPLACEMENT


1. REMOVE LUGGAGE COMPARTMENT OPENING TROUGH



## 2. INSTALL LUGGAGE COMPARTMENT OPENING TROUGH

HINT:

Inspect the fitting of the luggage compartment door and rear combination light, etc, before welding, since this affects the appearance of the finish.



- 3. MEASURING THE OPENING PORTION DIMENSIONS (See page BP-100)
- 4. APPLYING SEALER TO THE REAR LUGGAGE COMPARTMENT (See page PC-1)
- 5. APPLYING ANTI-RUST AGENT
- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.