POWER DOOR LOCK CONTROL SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

055Y6-0

HINT:

	Troubleshoot	in	accordance	with	the	procedure of	on t	the	following page	es.
--	--------------	----	------------	------	-----	--------------	------	-----	----------------	-----

1 VEHICLE BROUGHT TO WORKSHOP

2 CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05–2073)

3 DIAGNOSTIC TROUBLE CODE CHECK (See page 05–2074)

- (a) Check the diagnostic trouble code.
 - (1) Without code outputs, proceed to A.
 - (2) With code outputs, proceed to B.

B > Go to step 6

Α__

- 4 PROBLEM SYMPTOMS TABLE (See page 05–2079)
- (a) Without applicable symptoms, proceed to A.
- (b) With applicable symptoms, proceed to B.

B > Go to step 6

A

- 5 PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM
- (a) On-vehicle Inspection (See page 73-1).
- (b) Inspection (See page 73–3).
- (c) Terminals of ECU (See page 05–2076).
 - 6 ADJUSTMENT, REPAIR OR REPLACEMENT

END