
OVERHAUL

HINT:

COMPONENTS: See page 55-30

1. REMOVE AIR CONDITIONING PANEL SUB-ASSY (See page 71-9)



2. REMOVE HEATER CONTROL HOUSING

- (a) Remove the 2 screws.
- (b) Release the 10 fitting claws, remove the heater control housing.

550BZ-03