

O : Parts Location

l	Code	See Page	Code	See Page	Code	See Page	
-	G4	44					

: Junction Block and Wire Harness Connector

	Code	See Page	Junction Block and Wire Harness (Connector Location)	
	2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
Г	3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	E1 50 Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)	

: Ground Points

	Code	See Page	Ground Points Location
Г	IM	50	Instrument Panel Reinforcement RH