
INNER REAR VIEW MIRROR ASSY REPLACEMENT

700BU-01

HINT:

Installation is according to the reverse order of the removal.



1. REMOVE INNER REAR VIEW MIRROR ASSY

- (a) Remove the screw.
- (b) w/ Erectro chromic inner mirror:Remove the inner rear view mirror cover.
- (c) w/ Erectro chromic inner mirror:
 Disconnect the connector.
- (d) Remove the rear view inner mirror assembly.