line coding:

* what is line code:

is a pattern of: voltage or current or photons

* why to use line code?

تكون بعض الإشارات أكثر عرضة للخطأ من غيرها عند نقلها عبر قناة اتصال حيث أن فيزياء الاتصال أو وسيط التخزين تقيد مجموعة الإشارات التي يمكن استخدامها بشكل موثوق.

ففي بعض أنظمة الأتصال يكون المهم هو المحافظة على التزامن طول فترة الإرسال والإستقبال وفي بعض الأحيان نكون مقيدين بعرض لقناة الإتصال وأحياناً نريد كشف الأخطاء بكفاءة عالية وغيرها.

كل ما سبق يتعلق بقرار اختيار النوع الـ line code المستخدم لنظام الاتصال.

* clock Generator:

in some sorts of line codes need clock generator to inform circuits (Enocode and decodor) with the first of each bit and the bit duration as well

1) UNI - NRZ:

data {1: DC Bias in the tronsmission line 0: Represent by the absent of this bais




Ex: unipolar NRZ

2) *BIP* – *NRZ*:

 $\frac{data}{0:represented\ by\ one\ physical\ level\ (usually\ a\ positive\ volt)}{0:represented\ by\ another\ level\ (usually\ a\qquad volt)}$


Ex: UNI - NRZ and BIPNRZ:



0957404177 📞

(1)


(الأساف (المهنرين محسر العلي نظام



3) UNI - RZI:

 $data: \begin{cases} 1: Half \ a \ bit \ with \ (+voltage) \\ 0: No \ output \end{cases}$






0957404177

(2)

(الأستاذ (المهندس محسر العلي نظام

4) BIP - RZ:

 $data \begin{cases} 1: (+r) \ for \ the \ first \ half \ of \ bit \ return \ to \ zero \ at \ the \ 2^{ed} \\ 0: (-r) \ for \ the \ first \ half \ of \ bit \ return \ to \ zero \ at \ 2^{ed} \end{cases}$



$$f_s = R_b$$
 , $n = length (data)$

$$t=0: \ T_S: T_b-T_S$$
 تولید محور الزمن لنبضة واحدة Time semple Time bit

$$T=0:T_S:n^*\,T_b-T_S$$
 تولید محور الزمن لکل النبضات عدد الثبات المحدد ا

cpulse = [ones (1, length(t)/2, zero s(1, length(t)/2)];clock = [];

for i = 1:n

$$clock = [clock, cpulse];$$

end

و المناس العمال العام المحمد على نظام