
The pivot of the wave maker should be positioned 200mm from the back wall and 205mm above the base of the tank. The wave maker should be 200mm long with a 5mm clearance from the tank floor.



The tank is 200mm wide

A scale in mm should be placed in the tank so that the depth of water can be determined

Valves should be fitted in the tank so that the water can be drained