
PN_IDLE
PNC_TX_ENABLE
PNC_ACK_ACTIVATION
PNC_MONITOR_ACTIVATION
PNC_ENABLE_CHECK
A
PN_Active
Activation
PNC_REMOTELLY_ACTIVE
PNC_LOCALLY_ACTIVE
B
Deactivation
PNC_READY_SLEEP
PNC_PREPARE_SLEEP
C