

PNC
PNC_SUSD_ShutdownPermission
SSC
SSC_SOH_SecurityAccessError
SSC_E_SecureMessageMonitoringEvents
ERRH
ERRH_SOH_RejectedClearDiagReq
ERRH_SOH_ClearDiagReq
ERRH_E_BswEvent
SOH_ERRH_ClearRID0x02C0
SUM_SOH
SOH_SUSD_ShutdownPermission
SUSD_SOH_PermitExecution
BatteryVoltage_DisableNVMWrite
SUSD_SOH_ResetOccured
SUSD
DIAG_SOH_DiagSessionRequest
DIAG_SOH_GetMEC
DIAG_ECUResetRequest
DIAG_SOH_ReprogrammingRequest
DIAG
NvMService<n>
RoutineServices_<Clear_SUM_SOH_logs>
DataServices<SOH>Data<n>
ReadCurrentTime:
GetCounterValue()
Callback:
ProtectionHook()
ErrorHook()
OS
WdgM_IndividualMode<1....n>
WdgM_AliveSupervision
Callback:ShutdownNotificationToSoh()
DiagnosticReprogrammingRequest
SOH_BswM_Cry_SECP_Errors
RTE
DCM
WdgM
BswM
NvM