

SUM_SOH
SUM_DIAG
DIAG_ECUResetRequest
DIAG_SOH_GetMEC
DIAG_SOH_ReprogrammingRequest
DIAG_SOH_DiagSessionRequest
SUM_SUSD
BatteryVoltage_DisableNVMWrite
SOH_SUSD_ShutdownPermission
SUSD_SOH_PermitExecution
SUSD_SOH_ResetOccured
BatteryVoltageRange<Min>To<Max>
SUM_TCS
TCS_SWC_Clock
NvM
NvMService
WdgM
WdgM_AliveSupervision
WdgM_IndividualMode<1….n>
SOH_WdgM_IndividualMode_Errh
Filters
Time Window Filtter
Threshold Filtter
Reliability Monitors
Detectors
SSC_E_SecureMessageMonitoringEvents
SSC_SOH_SecurityAccessError
SUM_SSC
Callback: ProtectionHook()/ErrorHook()/
GetElapsedValue()
OS
PNC_SUSD_ShutdownPermission
SUM_PNC
RoutineServices_Clear_SUM_SOH_logs
DataServices<SOH>Data<n>
DCM
SOH_ERRH_ClearRID0x02C0
ERRH_E_BswEvent
ERRH_SOH_ClearDiagReq
ERRH_SOH_RejectedClearDiagReq
SUM_ERRH
DiagnosticReprogrammingRequest
SECPError_Notification
Callback :ShutdownNotificationToSoh()
BswM