
2025/5/29 晚上10:45 Contact Potential

Contact Potential

The *contact potential*, $\Delta \phi$ (measured in unit of energy, eV), is one of the most important parameters for understanding tip-induced band bending and tunneling spectroscopy. It is defined as the work function of the metallic tip, ϕ_m , minus that of the semiconducting sample, ϕ_s , where for the sample its work function is given by the electron affinity, χ , plus the difference in energy between the conduction band maximum and the Fermi-level, E_C - E_F . For the contact potential used throughout the SEMITIP program, it is assumed that we are taking the work function of the sample as it would be in the *absence* of any surface states (intrinsic or extrinsic). Such surface states can still be included in the program with no problem, but it's just that the contact potential, as a numerical parameter, corresponds to what would be measured experimentally on a surface with *no* surface states.

If, for example, a positive contact potential occurs, then, when a tip is brought towards a sample, *upwards* band bending will occur in the sample. The situation for an n-type sample is pictured below, with the surface region being depleted of electrons. It is clear that a nonzero electrostatic potential exists in the semiconductor, even though there is not applied voltage bias between the sample and tip.



A positive contact potential such as this will cause a tunneling spectrum to shift towards higher (more positive) sample voltages (i.e. towards the right), whereas a negative contact potential will shift the spectrum towards lower (more negative) sample voltages (towards the left).

In the above diagram, it is clear that the electrostatic potential energy within the probe tip, relative to a point deep inside the semiconductor, is given simply by $\Delta \varphi$. Application of some bias voltage V on the sample relative to the tip will further shift the electrostatic potential energy of the tip by eV(e) is the fundamental unit of charge, taken as usual to be positive), so that the total electrostatic potential energy of the tip is $\varphi_T = eV + \Delta \varphi$ as defined in Ref. 1. This quantity is the basic boundary condition used for the electrostatic solution within SEMITIP. In versions 1 and 2 is was φ_T itself that was entered as an input parameter. In version 3 and higher, separate parameters for V and $\Delta \varphi$ are entered. (In version 3 these parameters are used simply to compute the sum $eV + \Delta \varphi$, which is assigned to φ_T , whereas in versions 4 and higher, where tunnel currents are computed, the quantities V and $\Delta \varphi$ are needed individually for other purposes as well).

References:

1. R. M. Feenstra, Y. Dong, M. P. Semtsiv, and W. T. Masselink, *Influence of Tip-induced Band Bending on Tunneling Spectra of Semiconductor Surfaces*, Nanotechnology **18**, 044015 (2007). For preprint, see http://www.cmu.edu/physics/stm/publ/74/.