# Interrupt times measurement by software

# Software Manual Real Time Embedded System Course LAP – IC – FPFL – 2011

Version 0.2 (Preliminary)

Cagri Onal, René Beuchat

#### 1 Introduction

This guide has been prepared to help students following the Real Time Embedded System Course in I&C at EPFL. A development board FPGA4U is used during the laboratories with Quartus 10.1 and NIOS 10.1 from Altera and ModelSim-Altera from Mentor.

The latest copy of the tools can be found at LAP for personal installation:

(or you can follow http:\\www.altera.com to download the install files after registration).

This guide assumes that the users know how to use Quartus10.1, NIOS 10.1 and ModelSim-Altera 6.6.For starters, here are some manuals helping to use these tools:

\\lapsrv1\distribution\Laboratoires\LaboFPGA4U\Using\_NIOS2\_EDS\_10\_v1x.pdf

\\lapsrv1\distribution\Laboratoires\LaboFPGA4U\UsingQuartusII ModelSim v0.6x.pdf

## 2 Checking hardware components of the system working correctly

The hardware system to be designed for the interrupt analysis laboratory is as follows:

Conn	Мо	dule	Description	Clock	Ва	ase	End	IRQ
		cpu_0	Nios II Processor	[clk]				
$\overline{}$		instruction_master	Avalon Memory Mapped Master	clk_0				
$ $ $\prec$		data_master	Avalon Memory Mapped Master	[clk]		IRQ 0	IRQ	31 ←
ightharpoonup		jtag_debug_module	Avalon Memory Mapped Slave	[clk]	=0	0x04009000	0x040097ff	
	⊟	timer_0	Interval Timer	[clk]				
$  \hspace{.1cm}   \hspace{.1cm} \rightarrow \hspace{.1cm}$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x0400a040	0x0400a05f	<b>├</b> ि
	⊟	performance_counte	Performance Counter Unit	[clk]				
$\rightarrow$		control_slave	Avalon Memory Mapped Slave	clk_0	m <sup>2</sup>	0x0400a000	0x0400a03f	
		sdram_0	SDRAM Controller	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x02000000	0x03ffffff	
	⊟	onchip_memory2_0	On-Chip Memory (RAM or ROM)	[clk1]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x04004000	0x04007fff	
		jtag_uart_0	JTAG UART	[clk]				1
$  \rightarrow$		avalon_jtag_slave	Avaion Memory Mapped Slave	clk_0	m <sup>2</sup>	0x0400a110	0x0400a117	<b>├</b> —1
	⊟	epcs_flash_controlle	EPCS Serial Flash Controller	[clk]				
$\rightarrow$		epcs_control_port	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x04009800	0x04009fff	<u></u>
		pio_0	PIO (Parallel I/O)	[clk]				1
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>0</sup>	0x0400a080	0x0400a08f	<b>├</b> 3
	⊟	pio_1	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>2</sup>	0x0400a090	0x0400a09f	
		pio_2	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	min.	0x0400a0a0	0x0400a0af	
		pio_3	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>2</sup>	0x0400a0b0	0x0400a0bf	
		pio_4	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	mi <sup>n</sup>	0x0400a0c0	0x0400a0cf	
		pio_5	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	min.	0x0400a0d0	0x0400a0df	
		pio_6	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	min.	0x0400a0e0	0x0400a0ef	
	⊟	pio_7	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x0400a0f0	0x0400a0ff	
		pio_8	PIO (Parallel I/O)	[clk]				
$\rightarrow$		s1	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x0400a100	0x0400a10f	
		specific_counter_0	specific_counter	[clock_sink]				
$\rightarrow$		avalon_slave_0	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x0400a060	0x0400a07f	<b>├</b> 4
		ParPort_0	ParPort	[clock_sink]				
$\hookrightarrow$		avalon_slave_0	Avalon Memory Mapped Slave	clk_0	m <sup>n</sup>	0x0400a118	0x0400a11f	<b>├─</b> 5

Fig. 1. Hardware system

After the hardware system is designed with Quartus 10.1 and tested with ModelSim, the next step will be to write suitable software for each timing measurement. Before that, testing each hardware peripheral with a small software is a good idea and assure that your hardware is working correctly. After that, any problem that will be faced with can be solved by using appropriate software.

In this section, only general functionalities of these programmable specific interfaces will be tested. Interrupt tests with these will be given in section 3.

#### 2.1 Test of Specific Parallel Port

Following function first selects the parallel port as output, writes some value, then selects it as input and catches the input data and prints it on the console.

```
0 //Change the values if your register map is different than
#define IREGDIR
here
#define IREGPIN
#define IREGPORT
#define PARIRQEN 5
#define PARIROCLR 6
#define MODE_ALL_OUTPUT 0xFF
#define MODE_ALL_INPUT 0X00
#define ALL_IRQ_EN
                       0XFF
#define ALL_IRQ_CLR
                       0xFF
void test_parallel_port()
      volatile unsigned int k;
      while(1)
      {
      IOWR_8DIRECT(PARALLELPORT_0_BASE, IREGDIR, MODE_ALL_OUTPUT);
            //Select Parport as output
      alt_printf("iRegDir=%x\n", IORD_8DIRECT(PARALLELPORT_0_BASE, IREGDIR));
      //Read iRegDir to check whether it is written correct
      IOWR_8DIRECT(PARALLELPORT_0_BASE, IREGPORT, 0x9b);
            //Write Parport 0x9b as the output value
      alt_printf("iRegPort=%x\n", IORD_8DIRECT(PARALLELPORT_0_BASE, IREGPORT));
      //Read iRegPort to check whether it is written correct
      //Switch LEDS should give 0x9b, observe it
      for(k=0; k<1000000; k++); //software delay
      IOWR 8DIRECT(PARALLELPORT 0 BASE, IREGDIR, MODE ALL INPUT);
            //Select Parport as input
      alt_printf("iRegDir=%x\n", IORD_8DIRECT(PARALLELPORT_0_BASE, IREGDIR));
      //Read iRegDir to check whether it is written correct
      //Change the input value to a value different than 0x9b by changing switch
positions
      alt_printf("iRegPin=%x\n",IORD_8DIRECT(PARALLELPORT_0_BASE,IREGPIN));
      //Read iRegPin to take the input Parport value
      for(k=0;k<1000000;k++); //software delay
      }
```

Fig. 2. Test program for specific parallel port

Sample console output is as follows: (Note that the input at the 2<sup>nd</sup> loop is changed from **b4** to **94**)

```
iRegDir=ff --selected as output
iRegPort=9b --9b written as the output value
iRegDir=0 --selected as input
iRegPin=b4 --b4 taken as the input value, end of first loop
iRegDir=ff --selected as output
iRegPort=9b --9b written as the output value
iRegDir=0 --selected as input
```

#### 2.2 Test of Specific Counter

```
#define IRESETVAL 0 //Change the values if your register map is different than
here
#define ICOUNTER
                   0
#define IRZ
#define ISTART
#define ISTOP
                   3
#define IIRQEN
#define ICLREOT
                  OXFF000000 //Counter starts counting from this value
#define RESETVAL
#define IRQENVAL
#define IRQDISVAL
#define CLREOTVAL
#define ARBITVAL
                   0X0000FFFF //Arbitrary writedata value used for addresses 1,2,3
void test_counter()
IOWR(SPECIFIC_COUNTER_0_BASE, IRESETVAL, RESETVAL);
      //Reset value is loaded
IOWR(SPECIFIC_COUNTER_0_BASE, IRZ, ARBITVAL);
      //Reset activated to load the counter with the reset value
alt_printf("iCounter after reset= %x\n",IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
      //Check that counter is loaded with the reset value
IOWR(SPECIFIC_COUNTER_0_BASE, ISTART, ARBITVAL);
      //Start the counter
alt_printf("iCounter after start= %x\n",IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
      //Read a value from the running counter
IOWR(SPECIFIC_COUNTER_0_BASE, ISTOP, ARBITVAL);
alt_printf("iCounter after stop1= %x\n",IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
alt_printf("iCounter after stop2= %x\n",IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
      //Two consecutive reads to test that the counter is stopped. They should
      give
             the same result
IOWR(SPECIFIC_COUNTER_0_BASE, ISTART, ARBITVAL);
      //Restart the counter
alt_printf("iCounter after restart1=
%x\n", IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
alt_printf("iCounter after restart2=
%x\n", IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
      //Two consecutive reads to test that the counter is stopped. They should
     give different results
IOWR(SPECIFIC_COUNTER_0_BASE, ISTOP, ARBITVAL);
}
```

Fig. 3. Test program for specific counter

#### Sample console output is as follows:

```
iCounter after reset= ff000000
iCounter after start= ff000003
iCounter after stop1= ff030c95
iCounter after stop2= ff030c95
iCounter after restart1= ff030ca4
iCounter after restart2= ff06641a
```

#### 3 Interrupt times measurement tests

As mentioned in the class, to successfully generate and execute an ISR firstly depends on the enabling of the interrupts both at the processor and at the interface level. Thus, the programmer has to guarantee

this fact by modifying the registers of the processor (lenable register and PIE bit) and the interface(IRQen and IRQpend).

The required software for the interface side might be different for different interfaces thus it will be given with respect to the used interrupt source interface in the corresponding sections. However, for the processor side, it is almost the same and this one-line software for enabling the interrupts on the processor side is as follows:

```
alt_ic_isr_register(XXXX_0_IRQ_INTERRUPT_CONTROLLER_ID, XXXX_0_IRQ, my_isr, NULL, NULL
);
```

where XXXX can be either **TIMER** or **SPECIFIC\_COUNTER** or **PARALLELPORT** with respect to the used interrupt source interface. 3<sup>rd</sup> parameter "my\_isr" is the name of the ISR function whose prototype is

```
static void my_isr(void* context);
```

In the following sections, the software to measure the mentioned interrupt time is given in two parts; namely, the ISR(my\_isr) and the required software in the main function.

#### 3.1 Response time measurement

Response time can be measured with 3 different methods. The first one uses the timer from library, whereas the specific counter is used instead in the second method. Third method uses both the parallel port and logic analyzer to give a precise result.

#### 3.1.1 With Timer (from library)

```
int main()
void *NULL;
alt_ic_isr_register(TIMER_0_IRQ_INTERRUPT_CONTROLLER_ID,TIMER_0_IRQ,my_isr,
NULL, NULL);
flag=0; //Flag is a global variable
IOWR ALTERA AVALON TIMER CONTROL (TIMER 0 BASE, 0);
                                                          //Clear control register
IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE, 2);
                                                          //Continuous mode ON
IOWR_ALTERA_AVALON_TIMER_PERIODL(TIMER_0_BASE, 0xFFFF); //Set initial value
IOWR_ALTERA_AVALON_TIMER_PERIODH(TIMER_0_BASE, 0x00FF);
IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE,3);
                                                         //Enable timer interrupt
IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_O_BASE, 7);
                                                          //Start timer
while(1)
// Normal program routine HERE...
   if(flag)
      {
         alt_printf("%x \n", 0xffff-snap+1);
         flag=0;
         IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE,7); //Enable IRQ and Start
timer
};
return 0;
```

Fig. 4. Response time with timer (main part)

```
flag=1; //Flag is a global variable
}
```

Fig. 5. Response time with timer (ISR part)

#### 3.1.2 With Specific Counter

```
int main()
void *NULL;
alt_ic_isr_register(SPECIFIC_COUNTER_0_IRQ_INTERRUPT_CONTROLLER_ID, SPECIFIC_COUNTE
R_0_IRQ, my_isr, NULL, NULL);
flag=0; //Flag is a global variable
IOWR(SPECIFIC_COUNTER_0_BASE, IRESETVAL, RESETVAL); //Reset value is loaded
IOWR(SPECIFIC_COUNTER_0_BASE, IRZ, ARBITVAL);
                                                //Reset activated to load the
counter with the reset value
IOWR(SPECIFIC_COUNTER_0_BASE, IIRQEN, IRQENVAL);
                                                //Enable IRQ
IOWR(SPECIFIC_COUNTER_O_BASE, ISTART, ARBITVAL);
                                                //Start the counter
while (1)
// Normal program routine HERE...
     if(flag)
           alt_printf("%x \n", snap);
           flag=0;
           IOWR(SPECIFIC_COUNTER_O_BASE, IIRQEN, IRQENVAL); //Enable the
interrupt
           counter
           }
};
return 0;
```

Fig. 6. Response time with specific counter (main part)

```
static void my_isr(void* context)
{
    snap = IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER);
        IOWR(SPECIFIC_COUNTER_0_BASE, IIRQEN, IRQDISVAL); //Clear interrupt
        IOWR(SPECIFIC_COUNTER_0_BASE, ICLREOT, CLREOTVAL); //Clear iEOT
        IOWR(SPECIFIC_COUNTER_0_BASE, ISTOP, ARBITVAL); //Stop the counter
        IOWR(SPECIFIC_COUNTER_0_BASE, IRZ, ARBITVAL); //Reset the
counter
    flag=1; //Flag is a global variable
}
```

Fig. 7. Response time with specific counter (ISR part)

#### 3.1.3 With Specific Parallel Port and Logic Analyzer

The idea is to generate an interrupt by setting one bit of the parallel port and clear this bit at the beginning of the ISR. This gives a pulse whose duration at 1-level is the response time. This pulse can be measured by the logic analyzer. Note that the duration of the pulse at 0-level also gives the recovery time.

```
int main()
{
    void *NULL;
    alt_ic_isr_register(PARPORT_0_IRQ_INTERRUPT_CONTROLLER_ID, PARPORT_0_IRQ, my_i
    sr, NULL, NULL);
    IOWR_8DIRECT(PARPORT_0_BASE, IREGDIR, MODE_ALL_OUTPUT); //Selected as output
    IOWR_8DIRECT(PARPORT_0_BASE, IREGPORT, 0x00);
    IOWR_8DIRECT(PARPORT_0_BASE, PARIRQEN, ALL_IRQ_EN); //Enable IRQ on each bit
    while(1)
        IOWR_8DIRECT(PARPORT_0_BASE, IREGPORT, 0x02); //Bit2 is SET st IRQ
    generated
    return 0;
}
```

Fig. 8. Response time with specific parallel port & logic analyzer (main part)

Fig. 9. Response time with specific parallel port & logic analyzer (ISR part)

A sample logic analyzer output is as follows:




Fig. 10. Logic Analyzer output (recovery time)

#### 3.2 Recovery time measurement

During this measurement, while one of the interfaces is used as the IRQ generation source, the other one will help to determine the result.

#### 3.2.1 With Timer (from library) and Specific Counter

In this method, while timer is used as the IRQ source, specific counter will start counting from 0 at the end of ISR. A polling mechanism in the main function continuously checks the value of specific counter. Whenever we met a nonzero value, we print this value.

```
int main()
     void *NULL;
     alt_ic_isr_register(TIMER_0_IRQ_INTERRUPT_CONTROLLER_ID,TIMER_0_IRQ,my_isr,
NULL, NULL);
     IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE,0); //Clear control register
     IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE, 2);
                                                     //Continuous mode ON
     IOWR_ALTERA_AVALON_TIMER_PERIODL(TIMER_O_BASE, 0xffff);
     IOWR_ALTERA_AVALON_TIMER_PERIODH(TIMER_O_BASE, 0x00ff);
     IOWR(SPECIFIC_COUNTER_O_BASE, IRESETVAL, 0);
                                                     //Reset value(0) is
loaded
     IOWR(SPECIFIC_COUNTER_O_BASE, IRZ, ARBITVAL);
                                                     //Reset activated to load
the counter with the reset value
     IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE,3); //Enable timer interrupt
     IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE,7); //Start timer
while(1)
     while(IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER) == 0);
     alt_printf("%x \n", IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
     IOWR(SPECIFIC_COUNTER_O_BASE, ISTOP, ARBITVAL);
                                                     //Stop the counter
     IOWR(SPECIFIC_COUNTER_0_BASE, IRZ, ARBITVAL);
                                                      //Reset the counter
     };
return 0;
```

Fig. 11. Recovery time with timer & specific counter (main part)

Fig. 12. Recovery time with timer & specific counter (ISR part)

Page | 8

#### 3.2.2 With Specific Parallel Port and Specific Counter

Here, IRQ source is the specific parallel port and we measure recovery time by the specific counter value. First, parallel port is defined as input so that whenever the user changes the switch positions, an IRQ is generated. At the end of ISR, specific counter starts counting from 0. A polling mechanism in the main function detects that counter value is nonzero and prints it on the console.

```
int main()
     void *NULL;
      alt ic isr register (PARPORT 0 IRQ INTERRUPT CONTROLLER ID, PARPORT 0 IRQ, my i
sr, NULL, NULL);
      IOWR(SPECIFIC_COUNTER_0_BASE, IRESETVAL, 0);
                                                     //Reset value(0) is
loaded
      IOWR(SPECIFIC_COUNTER_0_BASE, IRZ, ARBITVAL); //Reset activated to load
the counter with the reset value
      IOWR_8DIRECT(PARPORT_0_BASE, IREGDIR, MODE_ALL_INPUT); //Selected as output
      IOWR_8DIRECT(PARPORT_0_BASE, IREGPORT, 0x00);
      IOWR_8DIRECT(PARPORT_0_BASE, PARIRQEN, ALL_IRQ_EN);
                                                          //Enable IRQ on each
bit
while (1)
     while(IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER) == 0);
      alt_printf("%x \n", IORD(SPECIFIC_COUNTER_0_BASE, ICOUNTER));
     IOWR(SPECIFIC_COUNTER_0_BASE, ISTOP, ARBITVAL); //Stop the counter
      IOWR(SPECIFIC_COUNTER_0_BASE, IRZ, ARBITVAL);
                                                          //Reset the counter
};
return 0;
```

Fig. 13. Recovery time with specific parallel port & specific counter (main part)

Fig. 14. Recovery time with specific parallel port & specific counter (ISR part)

#### 3.2.3 With Specific Parallel Port and Logic Analyzer

The idea is similar to the measurement of response time. This time, we set one bit of the parallel port of at the end of ISR and clear the same bit in the main program. Every clear operation results in a new interrupt since the parallel port interrupt is sensitive to both edges. Check 3.1.3 for implementation.

#### 3.3 Latency measurement

The specific parallel port and the logic analyzer are used for these measurements. The measurements are done in different levels with respect to their software overhead. More precise results are expected from the measurements done in Assembly level since its overhead is smaller. The software in the main program is same for both measurements.

```
int main()
{
    void *NULL;
```

```
alt_ic_isr_register(PARPORT_0_IRQ_INTERRUPT_CONTROLLER_ID, PARPORT_0_IRQ, my_i
sr, NULL, NULL);
    IOWR_8DIRECT(PARPORT_0_BASE, IREGDIR, MODE_ALL_OUTPUT); //Selected as output
    IOWR_8DIRECT(PARPORT_0_BASE, IREGPORT, 0x00);
    IOWR_8DIRECT(PARPORT_0_BASE, PARIRQEN, ALL_IRQ_EN); //Enable IRQ on each bit
while(1)
    IOWR_8DIRECT(PARPORT_0_BASE, IREGPORT, 0x02); //Bit2 is SET st IRQ
generated
return 0;
}
```

Fig. 15. Latency measurement (main part)

#### 3.3.1 Measurement in Clevel

The least overhead C level for latency measurement is the source file "alt\_irq\_handler.c". In the main function, we can create an interrupt by setting one bit of the parallel port which was cleared before. Then by clearing the same bit in this source code "alt\_irq\_handler.c" gives us a pulse whose duration is the latency and this pulse can be observed by the logic analyzer. The corresponding C code is as follows:

Fig. 16. Latency measurement (IRQ Handler in C)

With this method, we measure a latency of 70 cycles with a processor without cache.

#### 3.3.2 Measurement in Assembly level

The least overhead Assembly level for latency measurement is the source file "alt\_exception\_entry.S". In the main function, we can create an interrupt by setting one bit of the parallel port which was cleared before. Then by clearing the same bit in this source code "alt\_exception\_entry.S" gives us a pulse whose duration is the latency and this pulse can be observed by the logic analyzer. The corresponding Assembly code is as follows:

## 4 MicroC/OS-II

```
#include <stdio.h>
#include "includes.h"
#include "system.h"
#include "io.h"
```

```
#include "sys/alt_irq.h"
#include "altera_avalon_timer_regs.h"
/* Definition of Task Stacks */
#define TASK STACKSIZE
                               2048
         task1_stk[TASK_STACKSIZE];
OS_STK
OS_STK
         task2_stk[TASK_STACKSIZE];
OS_STK
         task3_stk[TASK_STACKSIZE];
OS_STK
         task4_stk[TASK_STACKSIZE];
/* Definition of Task Priorities */
#define TASK1_PRIORITY
#define TASK2_PRIORITY
#define TASK3_PRIORITY
                            3
#define TASK4_PRIORITY
#define QUEUE_SIZE 10
OS_EVENT *sem_res;
OS_FLAG_GRP *flag_res;
OS_FLAGS flags;
OS_EVENT *mail_res;
OS_EVENT *queue_res;
//unsigned char c = 0x0f;
typedef struct {
    unsigned char button_number;
    unsigned char edge;
} msg;
msg* msg_queue[10];
msg some_msg;
unsigned int start, stop;
```

Fig. 17. Common definitions

#### 4.1 Semaphore

```
void task_sem(void* pdata)
{
   INT8U err;
   while (1)
   {
      OSSemPend(sem_res,0,&err);
      IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
      stop = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
      if(err == OS_NO_ERR)
```

```
printf("Getting semaphore in : %u cycle\n", start - stop);
else
    printf("Not getting semaphore\n");
}
```

#### **EXPLANATION HERE**

#### 4.2 Flags

```
void task_flag(void* pdata)
{
    INT8U err;
    while (1)
    {
        OSFlagPend(flag_res, 0xf, OS_FLAG_WAIT_SET_ALL,0,&err);
        IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
        stop = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
        if(err == OS_NO_ERR)
            printf("Getting flag in : %u cycle\n", start - stop);
        else
            printf("Not getting flag\n");
     }
}
```

#### **EXPLANATION HERE**

```
void my_isr(void* context)
{
    OSFlagPost(flag_res, v,OS_FLAG_SET,&err);
    IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
    start = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
    IOWR(PIO_0_BASE,3,0x0f);
}
```

#### 4.3 Mailbox

```
void task_mail(void* pdata)
{
    INT8U err;
    msg* bla;

while (1)
    {
        bla = (struct msg*)OSMboxPend(mail_res, 0, &err);
        IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
        stop = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
        if(err == OS_NO_ERR)
            printf("Getting message in : %u cycles with button number %u and edge %02X\n",
        start - stop, bla->button_number, bla->edge);
        else
            printf("Not getting message\n");
     }
}
```

#### **EXPLANATION HERE**

```
void my_isr(void* context)
{
    some_msg.button_number = v;
    some_msg.edge = ((IORD(PIO_0_BASE,0)&0x1) == 0) ? 0x80 : 0;
    OSMboxPost(mail_res, &some_msg);
    IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
    start = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
    IOWR(PIO_0_BASE,3,0x0f);
}
```

#### 4.4 Queue

#### **EXPLANATION HERE**

```
void task_queue(void* pdata)
{
    INT8U err;
    msg* bla;

while (1)
    {
        bla = (struct msg*)OSQPend(queue_res, 0, &err);
        IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
        stop = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
        if(err == OS_NO_ERR)
            printf("Getting message from queue in : %u cycles with button number %u and edge %02X\n", start - stop, bla->button_number, bla->edge);
        else
            printf("Not getting message\n");
      }
}
```

```
void my_isr(void* context)
{
    some_msg.button_number = v;
    some_msg.edge = ((IORD(PIO_0_BASE,0)&0x1) == 0) ? 0x80 : 0;
    OSQPost(queue_res, &some_msg);
    IOWR_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE, 9);
    start = IORD_ALTERA_AVALON_TIMER_SNAPL(TIMER_0_BASE);
    IOWR(PIO_0_BASE,3,0x0f);
}
```

#### 4.5 Main Function

```
int main(void)
    INT8U err;
  //sem_res = OSSemCreate(1);
  //flag_res = OSFlagCreate(0,&err);
  //mail_res = OSMboxCreate(NULL);
  queue_res = OSQCreate(msg_queue, QUEUE_SIZE);
  IOWR ALTERA AVALON TIMER PERIODL(TIMER 0 BASE, 0xffff);
  IOWR ALTERA AVALON TIMER PERIODH(TIMER 0 BASE, 0x0000);
  IOWR ALTERA AVALON TIMER CONTROL (TIMER 0 BASE, 2);
  IOWR_ALTERA_AVALON_TIMER_CONTROL(TIMER_0_BASE, 6);
alt_ic_isr_register(PARALLELPORT_0_IRQ_INTERRUPT_CONTROLLER_ID,PARALLELPORT_0_IRQ,
my_isr,NULL,NULL);
  IOWR(PIO_0_BASE, 3, 0x0f);
  IOWR(PIO_0_BASE, 2, 0x0f);
 /*
  OSTaskCreateExt(task_sem,
                   NULL,
                   (void *)&task1_stk[TASK_STACKSIZE-1],
                   TASK1_PRIORITY,
                   TASK1_PRIORITY,
                   task1 stk,
                   TASK STACKSIZE,
                   NULL,
                   0);
  OSTaskCreateExt(task_flag,
                   NULL,
                   (void *)&task2_stk[TASK_STACKSIZE-1],
                   TASK2_PRIORITY,
                   TASK2_PRIORITY,
                   task2_stk,
                   TASK_STACKSIZE,
                   NULL,
                   0);
  OSTaskCreateExt(task_mail,
                   NULL,
                   (void *)&task3_stk[TASK_STACKSIZE-1],
                   TASK3_PRIORITY,
                   TASK3_PRIORITY,
                   task3_stk,
                   TASK_STACKSIZE,
```

# 5 How to choose SRAM/SDRAM, With/Without Cache and their comparison

# **Summary**

1	Intr	roducti	ion	1
2			hardware components of the system working correctly	
	2.1		of Specific Parallel Port	
	2.2		of Specific Counter	
3	Inte	errupt	times measurement tests	4
	3.1	Resp	onse time measurement	5
3.1.1		.1	With Timer (from library)	5
	3.1.	.2	With Specific Counter	6
	3.1.	.3	With Specific Parallel Port and Logic Analyzer	6
	3.2	Reco	very time measurement	7
	3.2.	.1	With Timer (from library) and Specific Counter	8
	3.2.	.2	With Specific Parallel Port and Specific Counter	8
	3.2.3 With Specific Parallel Port and		With Specific Parallel Port and Logic Analyzer	9
	3.3	Later	ncy measurement	9
	3.3.	.1	Measurement in C level	. 10
	3.3.	.2	Measurement in Assembly level	. 10
4	Mic	croC/O	S-II	. 10
	4.1	Sema	aphore	. 11
	4.2	Flags	;	. 12
	4.3	Maill	box	. 13
4.4 Que		Quei	ıe	. 14
	4.5	Main	n Function	. 15
5	Hov	w to ch	noose SRAM/SDRAM, With/Without Cache and their comparison	. 16
Li	st of Fig	gures		. 18

# **List of Figures**

Fig. 1.	Hardware system	2
Fig. 2.	Test program for specific parallel port	3
Fig. 3.	Test program for specific counter	4
Fig. 4.	Response time with timer (main part)	5
Fig. 5.	Response time with timer (ISR part)	6
Fig. 6.	Response time with specific counter (main part)	6
Fig. 7.	Response time with specific counter (ISR part)	6
Fig. 8.	Response time with specific parallel port & logic analyzer (main part)	7
Fig. 9.	Response time with specific parallel port & logic analyzer (ISR part)	7
Fig. 10.	Logic Analyzer output (recovery time)	7
Fig. 11.	Recovery time with timer & specific counter (main part)	8
Fig. 12.	Recovery time with timer & specific counter (ISR part)	8
Fig. 13.	Recovery time with specific parallel port & specific counter (main part)	9
Fig. 14.	Recovery time with specific parallel port & specific counter (ISR part)	9
Fig. 15.	Latency measurement (main part)	. 10
Fig. 16.	Latency measurement (IRQ Handler in C)	. 10
Fig. 17.	Common definitions	. 11