

C28SOI_IO_EXT_ANAF_ANA_EG Databook

August 2016

CORNERCELL_EXT_ANA_FC_LIN

Cell Description

CORNERCELL_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 6400.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125

ESDSUB_EXT_ANA_CL_LIN

Cell Description

ESDSUB_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde
best 1.10 -40	1.131e-07
typ 1.00 25	1.020e-07
worst 0.90 125	2.082e-07



ESDSUB_EXT_ANA_FC_LIN

Cell Description

ESDSUB_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde
best 1.10 -40	1.131e-07
typ 1.00 25	1.020e-07
worst 0.90 125	2.082e-07



FILLCELL_1GRID_EXT_ANA_CL_LIN

Cell Description

FILLCELL_1GRID_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_1GRID_EXT_ANA_FC_LIN

Cell Description

FILLCELL_1GRID_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_1UM_EXT_ANA_CL_LIN

Cell Description

FILLCELL_1UM_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 80.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_1UM_EXT_ANA_FC_LIN

Cell Description

FILLCELL_1UM_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 80.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_5UM_EXT_ANA_CL_LIN

Cell Description

FILLCELL_5UM_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 400.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_5UM_EXT_ANA_FC_LIN

Cell Description

FILLCELL_5UM_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 400.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_10UM_EXT_ANA_CL_LIN

Cell Description

FILLCELL_10UM_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 800.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_10UM_EXT_ANA_FC_LIN

Cell Description

FILLCELL_10UM_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 800.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_END_LEFT_EXT_ANA_CL_LIN

Cell Description

FILLCELL_END_LEFT_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1440.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_END_LEFT_EXT_ANA_FC_LIN

Cell Description

FILLCELL_END_LEFT_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1440.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



FILLCELL_END_RIGHT_EXT_ANA_CL_LIN

Cell Description

FILLCELL_END_RIGHT_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1440.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



FILLCELL_END_RIGHT_EXT_ANA_FC_LIN

Cell Description

FILLCELL_END_RIGHT_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1440.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



FILLCELL_ESD_1V0_EXT_ANA_CL_LIN

Cell Description

FILLCELL_ESD_1V0_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW) vdde1v0	
best 1.10 -40	1.039e-06
typ 1.00 25	1.356e-05
worst 0.90 125	1.400e-03



FILLCELL_ESD_1V0_EXT_ANA_FC_LIN

Cell Description

FILLCELL_ESD_1V0_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW) vdde1v0	
best 1.10 -40	1.039e-06
typ 1.00 25	1.356e-05
worst 0.90 125	1.400e-03



FILLCELL_ESD_1V8_EXT_ANA_CL_LIN

Cell Description

FILLCELL_ESD_1V8_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW) vdde1v8	
best 1.10 -40	4.045e-04
typ 1.00 25	5.645e-05
worst 0.90 125	2.821e-04



FILLCELL_ESD_1V8_EXT_ANA_FC_LIN

Cell Description

FILLCELL_ESD_1V8_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v8
best 1.10 -40	4.045e-04
typ 1.00 25	5.645e-05
worst 0.90 125	2.821e-04



FILLCELL_ESD_3V3_EXT_ANA_CL_LIN

Cell Description

FILLCELL_ESD_3V3_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde3v3	
best 1.10 -40	8.621e-04	
typ 1.00 25	5.342e-05	
worst 0.90 125	5.567e-04	



FILLCELL_ESD_3V3_EXT_ANA_FC_LIN

Cell Description

FILLCELL_ESD_3V3_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde3v3	
best 1.10 -40	8.621e-04	
typ 1.00 25	5.342e-05	
worst 0.90 125	5.567e-04	



FILLCELL_FEEDTHROUGH_EXT_ANA_CL_LIN

Cell Description

FILLCELL_FEEDTHROUGH_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



FILLCELL_STEP_BTB_EXT_ANAF_TO_CSF_FC_2ROWS

Cell Description

FILLCELL_STEP_BTB_EXT_ANAF_TO_CSF_FC_2ROWS

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1661.640

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Parameter	best 1.10 -40	typ 1.00 25	worst 0.90 125
ASRCN[0] Input Cap.	0.0200	0.0200	0.0200
ASRCN[0] Max Load	10000.000	10000.000	10000.000
ASRCN[1] Input Cap.	0.0200	0.0200	0.0200
ASRCN[1] Max Load	10000.000	10000.000	10000.000
ASRCN[2] Input Cap.	0.0200	0.0200	0.0200
ASRCN[2] Max Load	10000.000	10000.000	10000.000
ASRCN[3] Input Cap.	0.0200	0.0200	0.0200
ASRCN[3] Max Load	10000.000	10000.000	10000.000
ASRCN[4] Input Cap.	0.0200	0.0200	0.0200
ASRCN[4] Max Load	10000.000	10000.000	10000.000
ASRCN[5] Input Cap.	0.0200	0.0200	0.0200
ASRCN[5] Max Load	10000.000	10000.000	10000.000
ASRCN[6] Input Cap.	0.0200	0.0200	0.0200
ASRCN[6] Max Load	10000.000	10000.000	10000.000
ASRCP[0] Input Cap.	0.0200	0.0200	0.0200
ASRCP[0] Max Load	10000.000	10000.000	10000.000
ASRCP[1] Input Cap.	0.0200	0.0200	0.0200
ASRCP[1] Max Load	10000.000	10000.000	10000.000
ASRCP[2] Input Cap.	0.0200	0.0200	0.0200
ASRCP[2] Max Load	10000.000	10000.000	10000.000
ASRCP[3] Input Cap.	0.0200	0.0200	0.0200
ASRCP[3] Max Load	10000.000	10000.000	10000.000



ASRCP[4] Input Cap.	0.0200	0.0200	0.0200
ASRCP[4] Max Load	10000.000	10000.000	10000.000
ASRCP[5] Input Cap.	0.0200	0.0200	0.0200
ASRCP[5] Max Load	10000.000	10000.000	10000.000
ASRCP[6] Input Cap.	0.0200	0.0200	0.0200
ASRCP[6] Max Load	10000.000	10000.000	10000.000
REFIOA Input Cap.	0.0200	0.0200	0.0200
REFIOA Max Load	10000.000	10000.000	10000.000
REFIOB Input Cap.	0.0200	0.0200	0.0200
REFIOB Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vddedig
best 1.10 -40	5.446e-08
typ 1.00 25	5.203e-08
worst 0.90 125	1.570e-07



FILLCELL_STEP_BTB_EXT_ANAF_TO_CSF_FC_LIN

Cell Description

FILLCELL_STEP_BTB_EXT_ANAF_TO_CSF_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1661.640

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Farameter	best 1.10 -40	typ 1.00 25	worst 0.90 125
ASRCN[0] Input Cap.	0.0200	0.0200	0.0200
ASRCN[0] Max Load	10000.000	10000.000	10000.000
ASRCN[1] Input Cap.	0.0200	0.0200	0.0200
ASRCN[1] Max Load	10000.000	10000.000	10000.000
ASRCN[2] Input Cap.	0.0200	0.0200	0.0200
ASRCN[2] Max Load	10000.000	10000.000	10000.000
ASRCN[3] Input Cap.	0.0200	0.0200	0.0200
ASRCN[3] Max Load	10000.000	10000.000	10000.000
ASRCN[4] Input Cap.	0.0200	0.0200	0.0200
ASRCN[4] Max Load	10000.000	10000.000	10000.000
ASRCN[5] Input Cap.	0.0200	0.0200	0.0200
ASRCN[5] Max Load	10000.000	10000.000	10000.000
ASRCN[6] Input Cap.	0.0200	0.0200	0.0200
ASRCN[6] Max Load	10000.000	10000.000	10000.000
ASRCP[0] Input Cap.	0.0200	0.0200	0.0200
ASRCP[0] Max Load	10000.000	10000.000	10000.000
ASRCP[1] Input Cap.	0.0200	0.0200	0.0200
ASRCP[1] Max Load	10000.000	10000.000	10000.000
ASRCP[2] Input Cap.	0.0200	0.0200	0.0200
ASRCP[2] Max Load	10000.000	10000.000	10000.000
ASRCP[3] Input Cap.	0.0200	0.0200	0.0200
ASRCP[3] Max Load	10000.000	10000.000	10000.000



ASRCP[4] Input Cap.	0.0200	0.0200	0.0200
ASRCP[4] Max Load	10000.000	10000.000	10000.000
ASRCP[5] Input Cap.	0.0200	0.0200	0.0200
ASRCP[5] Max Load	10000.000	10000.000	10000.000
ASRCP[6] Input Cap.	0.0200	0.0200	0.0200
ASRCP[6] Max Load	10000.000	10000.000	10000.000
REFIOA Input Cap.	0.0200	0.0200	0.0200
REFIOA Max Load	10000.000	10000.000	10000.000
REFIOB Input Cap.	0.0200	0.0200	0.0200
REFIOB Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vddedig
best 1.10 -40	5.446e-08
typ 1.00 25	5.203e-08
worst 0.90 125	1.570e-07



FILLCELL_STEP_EXT_ANAF_TO_CSF_FC_2ROWS

Cell Description

FILLCELL_STEP_EXT_ANAF_TO_CSF_FC_2ROWS

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1661.640

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter		Value(pF)	
Parameter	best 1.10 -40	typ 1.00 25	worst 0.90 125
ASRCN[0] Input Cap.	0.0200	0.0200	0.0200
ASRCN[0] Max Load	10000.000	10000.000	10000.000
ASRCN[1] Input Cap.	0.0200	0.0200	0.0200
ASRCN[1] Max Load	10000.000	10000.000	10000.000
ASRCN[2] Input Cap.	0.0200	0.0200	0.0200
ASRCN[2] Max Load	10000.000	10000.000	10000.000
ASRCN[3] Input Cap.	0.0200	0.0200	0.0200
ASRCN[3] Max Load	10000.000	10000.000	10000.000
ASRCN[4] Input Cap.	0.0200	0.0200	0.0200
ASRCN[4] Max Load	10000.000	10000.000	10000.000
ASRCN[5] Input Cap.	0.0200	0.0200	0.0200
ASRCN[5] Max Load	10000.000	10000.000	10000.000
ASRCN[6] Input Cap.	0.0200	0.0200	0.0200
ASRCN[6] Max Load	10000.000	10000.000	10000.000
ASRCP[0] Input Cap.	0.0200	0.0200	0.0200
ASRCP[0] Max Load	10000.000	10000.000	10000.000
ASRCP[1] Input Cap.	0.0200	0.0200	0.0200
ASRCP[1] Max Load	10000.000	10000.000	10000.000
ASRCP[2] Input Cap.	0.0200	0.0200	0.0200
ASRCP[2] Max Load	10000.000	10000.000	10000.000
ASRCP[3] Input Cap.	0.0200	0.0200	0.0200
ASRCP[3] Max Load	10000.000	10000.000	10000.000



ASRCP[4] Input Cap.	0.0200	0.0200	0.0200
ASRCP[4] Max Load	10000.000	10000.000	10000.000
ASRCP[5] Input Cap.	0.0200	0.0200	0.0200
ASRCP[5] Max Load	10000.000	10000.000	10000.000
ASRCP[6] Input Cap.	0.0200	0.0200	0.0200
ASRCP[6] Max Load	10000.000	10000.000	10000.000
REFIOA Input Cap.	0.0200	0.0200	0.0200
REFIOA Max Load	10000.000	10000.000	10000.000
REFIOB Input Cap.	0.0200	0.0200	0.0200
REFIOB Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCELL_STEP_EXT_ANAF_TO_CSF_FC_LIN

Cell Description

FILLCELL_STEP_EXT_ANAF_TO_CSF_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1661.640

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Farameter	best 1.10 -40	typ 1.00 25	worst 0.90 125
ASRCN[0] Input Cap.	0.0200	0.0200	0.0200
ASRCN[0] Max Load	10000.000	10000.000	10000.000
ASRCN[1] Input Cap.	0.0200	0.0200	0.0200
ASRCN[1] Max Load	10000.000	10000.000	10000.000
ASRCN[2] Input Cap.	0.0200	0.0200	0.0200
ASRCN[2] Max Load	10000.000	10000.000	10000.000
ASRCN[3] Input Cap.	0.0200	0.0200	0.0200
ASRCN[3] Max Load	10000.000	10000.000	10000.000
ASRCN[4] Input Cap.	0.0200	0.0200	0.0200
ASRCN[4] Max Load	10000.000	10000.000	10000.000
ASRCN[5] Input Cap.	0.0200	0.0200	0.0200
ASRCN[5] Max Load	10000.000	10000.000	10000.000
ASRCN[6] Input Cap.	0.0200	0.0200	0.0200
ASRCN[6] Max Load	10000.000	10000.000	10000.000
ASRCP[0] Input Cap.	0.0200	0.0200	0.0200
ASRCP[0] Max Load	10000.000	10000.000	10000.000
ASRCP[1] Input Cap.	0.0200	0.0200	0.0200
ASRCP[1] Max Load	10000.000	10000.000	10000.000
ASRCP[2] Input Cap.	0.0200	0.0200	0.0200
ASRCP[2] Max Load	10000.000	10000.000	10000.000
ASRCP[3] Input Cap.	0.0200	0.0200	0.0200
ASRCP[3] Max Load	10000.000	10000.000	10000.000



ASRCP[4] Input Cap.	0.0200	0.0200	0.0200
ASRCP[4] Max Load	10000.000	10000.000	10000.000
ASRCP[5] Input Cap.	0.0200	0.0200	0.0200
ASRCP[5] Max Load	10000.000	10000.000	10000.000
ASRCP[6] Input Cap.	0.0200	0.0200	0.0200
ASRCP[6] Max Load	10000.000	10000.000	10000.000
REFIOA Input Cap.	0.0200	0.0200	0.0200
REFIOA Max Load	10000.000	10000.000	10000.000
REFIOB Input Cap.	0.0200	0.0200	0.0200
REFIOB Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCUTCELL_ALL_EXT_ANA_FC_LIN

Cell Description

FILLCUTCELL_ALL_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1208.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdderight
best 1.10 -40	1.992e-07
typ 1.00 25	1.812e-07
worst 0.90 125	3.468e-07



FILLCUTCELL_GNDE_EXT_ANA_CL_LIN

Cell Description

FILLCUTCELL_GNDE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 128.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)
best 1.10 -40
typ 1.00 25
worst 0.90 125



FILLCUTCELL_GNDE_EXT_ANA_FC_LIN

Cell Description

FILLCUTCELL_GNDE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 128.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



FILLCUTCELL_VDDE_EXT_ANA_CL_LIN

Cell Description

FILLCUTCELL_VDDE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 128.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



FILLCUTCELL_VDDE_EXT_ANA_FC_LIN

Cell Description

FILLCUTCELL_VDDE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 128.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



GNDCORE_EXT_ANA_CL_LIN

Cell Description

GNDCORE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STE.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 2400.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde
best 1.10 -40	3.093e-07
typ 1.00 25	2.805e-07
worst 0.90 125	5.019e-07



GNDCORE_EXT_ANA_FC_LIN

Cell Description

GNDCORE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 2400.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde	
best 1.10 -40	3.093e-07	
typ 1.00 25	2.805e-07	
worst 0.90 125	5.019e-07	



GNDE_ESD_1V0_EXT_ANA_CL_LIN

Cell Description

GNDE_ESD_1V0_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v0	
best 1.10 -40	1.039e-06	
typ 1.00 25	1.356e-05	
worst 0.90 125	1.400e-03	



GNDE_ESD_1V0_EXT_ANA_FC_LIN

Cell Description

GNDE_ESD_1V0_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v0	
best 1.10 -40	1.039e-06	
typ 1.00 25	1.356e-05	
worst 0.90 125	1.400e-03	



GNDE_ESD_1V8_EXT_ANA_CL_LIN

Cell Description

GNDE_ESD_1V8_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v8	
best 1.10 -40	4.045e-04	
typ 1.00 25	5.645e-05	
worst 0.90 125	2.821e-04	



GNDE_ESD_1V8_EXT_ANA_FC_LIN

Cell Description

GNDE_ESD_1V8_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v8	
best 1.10 -40	4.045e-04	
typ 1.00 25	5.645e-05	
worst 0.90 125	2.821e-04	



GNDE_NOESD_EXT_ANA_CL_LIN

Cell Description

GNDE_NOESD_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



GNDE_NOESD_EXT_ANA_FC_LIN

Cell Description

GNDE_NOESD_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)		
best 1.10 -40		
typ 1.00 25		
worst 0.90 125		



IO_20UM_3V3_50OHMS_EXT_ANA_CL_LIN

Cell Description

IO_20UM_3V3_50OHMS_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
	best 1.10 -40	typ 1.00 25	worst 0.90 125
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	1.160e-07
typ 1.00 25	1.087e-07
worst 0.90 125	5.318e-07



IO_20UM_3V3_50OHMS_EXT_ANA_FC_LIN

Cell Description

IO_20UM_3V3_50OHMS_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
	best 1.10 -40	typ 1.00 25	worst 0.90 125
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	1.160e-07
typ 1.00 25	1.087e-07
worst 0.90 125	5.318e-07



IO_20UM_3V3_EXT_ANA_CL_LIN

Cell Description

IO_20UM_3V3_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
	best 1.10 -40	typ 1.00 25	worst 0.90 125
IO Input Cap.	1.0000	1.0000	1.0000
IO Max Load	10000.000	10000.000	10000.000
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	1.161e-07
typ 1.00 25	1.088e-07
worst 0.90 125	5.320e-07



IO_20UM_3V3_EXT_ANA_FC_LIN

Cell Description

IO_20UM_3V3_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Faiailletei	best 1.10 -40	typ 1.00 25	worst 0.90 125
IO Input Cap.	1.0000	1.0000	1.0000
IO Max Load	10000.000	10000.000	10000.000
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	1.161e-07
typ 1.00 25	1.088e-07
worst 0.90 125	5.320e-07



IO_20UM_50OHMS_EXT_ANA_CL_LIN

Cell Description

IO_20UM_50OHMS_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Faiailletei	best 1.10 -40	typ 1.00 25	worst 0.90 125
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	2.869e-08
typ 1.00 25	2.604e-08
worst 0.90 125	1.191e-07



IO_20UM_50OHMS_EXT_ANA_FC_LIN

Cell Description

IO_20UM_50OHMS_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Faiailletei	best 1.10 -40	typ 1.00 25	worst 0.90 125
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	2.869e-08
typ 1.00 25	2.604e-08
worst 0.90 125	1.191e-07



IO_20UM_EXT_ANA_CL_LIN

Cell Description

IO_20UM_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STE.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Devementes	Value(pF)		
Parameter	best 1.10 -40	typ 1.00 25	worst 0.90 125
IO Input Cap.	1.0000	1.0000	1.0000
IO Max Load	10000.000	10000.000	10000.000
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	2.878e-08
typ 1.00 25	2.610e-08
worst 0.90 125	1.192e-07



IO_20UM_EXT_ANA_FC_LIN

Cell Description

IO_20UM_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 1600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Faiailletei	best 1.10 -40	typ 1.00 25	worst 0.90 125
IO Input Cap.	1.0000	1.0000	1.0000
IO Max Load	10000.000	10000.000	10000.000
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	2.878e-08
typ 1.00 25	2.610e-08
worst 0.90 125	1.192e-07



IO_UHF_EXT_ANA_CL_LIN

Cell Description

IO_UHF_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter	Value(pF)		
Faiailletei	best 1.10 -40	typ 1.00 25	worst 0.90 125
IO Input Cap.	1.0000	1.0000	1.0000
IO Max Load	10000.000	10000.000	10000.000
IOPAD Input Cap.	0.0200	0.0200	0.0200
IOPAD Max Load	10000.000	10000.000	10000.000
RES Input Cap.	0.0200	0.0200	0.0200
RES Max Load	10000.000	10000.000	10000.000

Default Leakage Power (mW)	vdde
best 1.10 -40	9.759e-08
typ 1.00 25	8.267e-08
worst 0.90 125	1.687e-07



IO_UHF_EXT_ANA_FC_LIN

Cell Description

IO_UHF_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Cell Capacitance

Parameter		Value(pF)		
Faiailletei	best 1.10 -40	typ 1.00 25	worst 0.90 125	
IO Input Cap.	1.0000	1.0000	1.0000	
IO Max Load	10000.000	10000.000	10000.000	
IOPAD Input Cap.	0.0200	0.0200	0.0200	
IOPAD Max Load	10000.000	10000.000	10000.000	
RES Input Cap.	0.0200	0.0200	0.0200	
RES Max Load	10000.000	10000.000	10000.000	

Default Leakage Power (mW)	vdde
best 1.10 -40	9.759e-08
typ 1.00 25	8.267e-08
worst 0.90 125	1.687e-07



VDDCORE_1V0_ESDSUB_EXT_ANA_CL_LIN

Cell Description

VDDCORE_1V0_ESDSUB_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v0	vdde
best 1.10 -40	2.792e-06	0.000e+00
typ 1.00 25	4.441e-05	0.000e+00
worst 0.90 125	5.124e-03	0.000e+00



VDDCORE_1V0_ESDSUB_EXT_ANA_FC_LIN

Cell Description

VDDCORE_1V0_ESDSUB_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v0	vdde
best 1.10 -40	2.792e-06	0.000e+00
typ 1.00 25	4.441e-05	0.000e+00
worst 0.90 125	5.124e-03	0.000e+00



VDDCORE_1V0_GNDCORE_EXT_ANA_CL_LIN

Cell Description

VDDCORE_1V0_GNDCORE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v0	vdde
best 1.10 -40	2.792e-06	0.000e+00
typ 1.00 25	4.441e-05	0.000e+00
worst 0.90 125	5.124e-03	0.000e+00



VDDCORE_1V0_GNDCORE_EXT_ANA_FC_LIN

Cell Description

VDDCORE_1V0_GNDCORE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v0	vdde
best 1.10 -40	2.792e-06	0.000e+00
typ 1.00 25	4.441e-05	0.000e+00
worst 0.90 125	5.124e-03	0.000e+00



VDDCORE_1V0_GNDE_EXT_ANA_CL_LIN

Cell Description

VDDCORE_1V0_GNDE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v0	vdde
best 1.10 -40	2.791e-06	0.000e+00
typ 1.00 25	4.441e-05	0.000e+00
worst 0.90 125	5.124e-03	0.000e+00



VDDCORE_1V0_GNDE_EXT_ANA_FC_LIN

Cell Description

VDDCORE_1V0_GNDE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v0	vdde
best 1.10 -40	2.791e-06	0.000e+00
typ 1.00 25	4.441e-05	0.000e+00
worst 0.90 125	5.124e-03	0.000e+00



VDDCORE_1V8_ESDSUB_EXT_ANA_CL_LIN

Cell Description

VDDCORE_1V8_ESDSUB_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v8	vdde
best 1.10 -40	6.517e-04	0.000e+00
typ 1.00 25	9.134e-05	0.000e+00
worst 0.90 125	4.288e-04	0.000e+00



VDDCORE_1V8_ESDSUB_EXT_ANA_FC_LIN

Cell Description

VDDCORE_1V8_ESDSUB_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v8	vdde
best 1.10 -40	6.517e-04	0.000e+00
typ 1.00 25	9.134e-05	0.000e+00
worst 0.90 125	4.288e-04	0.000e+00



VDDCORE_1V8_GNDCORE_EXT_ANA_CL_LIN

Cell Description

VDDCORE_1V8_GNDCORE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v8	vdde
best 1.10 -40	6.517e-04	0.000e+00
typ 1.00 25	9.133e-05	0.000e+00
worst 0.90 125	4.288e-04	0.000e+00



VDDCORE_1V8_GNDCORE_EXT_ANA_FC_LIN

Cell Description

VDDCORE_1V8_GNDCORE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v8	vdde
best 1.10 -40	6.517e-04	0.000e+00
typ 1.00 25	9.133e-05	0.000e+00
worst 0.90 125	4.288e-04	0.000e+00



VDDCORE_1V8_GNDE_EXT_ANA_CL_LIN

Cell Description

VDDCORE_1V8_GNDE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v8	vdde
best 1.10 -40	6.517e-04	0.000e+00
typ 1.00 25	9.134e-05	0.000e+00
worst 0.90 125	4.288e-04	0.000e+00



VDDCORE_1V8_GNDE_EXT_ANA_FC_LIN

Cell Description

VDDCORE_1V8_GNDE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 5600.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore1v8	vdde
best 1.10 -40	6.517e-04	0.000e+00
typ 1.00 25	9.134e-05	0.000e+00
worst 0.90 125	4.288e-04	0.000e+00



VDDCORE_3V3_ESDSUB_EXT_ANA_CL_LIN

Cell Description

VDDCORE_3V3_ESDSUB_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore3v3	vdde
best 1.10 -40	8.622e-04	0.000e+00
typ 1.00 25	5.350e-05	0.000e+00
worst 0.90 125	5.569e-04	0.000e+00



VDDCORE_3V3_ESDSUB_EXT_ANA_FC_LIN

Cell Description

VDDCORE_3V3_ESDSUB_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore3v3	vdde
best 1.10 -40	8.622e-04	0.000e+00
typ 1.00 25	5.350e-05	0.000e+00
worst 0.90 125	5.569e-04	0.000e+00



VDDCORE_3V3_GNDCORE_EXT_ANA_CL_LIN

Cell Description

VDDCORE_3V3_GNDCORE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore3v3	vdde
best 1.10 -40	8.622e-04	0.000e+00
typ 1.00 25	5.350e-05	8.126e-23
worst 0.90 125	5.569e-04	0.000e+00



VDDCORE_3V3_GNDCORE_EXT_ANA_FC_LIN

Cell Description

VDDCORE_3V3_GNDCORE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore3v3	vdde
best 1.10 -40	8.622e-04	0.000e+00
typ 1.00 25	5.350e-05	8.126e-23
worst 0.90 125	5.569e-04	0.000e+00



VDDCORE_3V3_GNDE_EXT_ANA_CL_LIN

Cell Description

VDDCORE_3V3_GNDE_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore3v3	vdde
best 1.10 -40	8.622e-04	0.000e+00
typ 1.00 25	5.350e-05	9.126e-23
worst 0.90 125	5.569e-04	0.000e+00



VDDCORE_3V3_GNDE_EXT_ANA_FC_LIN

Cell Description

VDDCORE_3V3_GNDE_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vddcore3v3	vdde
best 1.10 -40	8.622e-04	0.000e+00
typ 1.00 25	5.350e-05	9.126e-23
worst 0.90 125	5.569e-04	0.000e+00



VDDE_ESD_1V0_EXT_ANA_CL_LIN

Cell Description

VDDE_ESD_1V0_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v0
best 1.10 -40	1.039e-06
typ 1.00 25	1.356e-05
worst 0.90 125	1.400e-03



VDDE_ESD_1V0_EXT_ANA_FC_LIN

Cell Description

VDDE_ESD_1V0_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v0
best 1.10 -40	1.039e-06
typ 1.00 25	1.356e-05
worst 0.90 125	1.400e-03



VDDE_ESD_1V8_EXT_ANA_CL_LIN

Cell Description

VDDE_ESD_1V8_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v8
best 1.10 -40	4.045e-04
typ 1.00 25	5.645e-05
worst 0.90 125	2.821e-04



VDDE_ESD_1V8_EXT_ANA_FC_LIN

Cell Description

VDDE_ESD_1V8_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde1v8
best 1.10 -40	4.045e-04
typ 1.00 25	5.645e-05
worst 0.90 125	2.821e-04



VDDE_GNDE_ESD_3V3_EXT_ANA_CL_LIN

Cell Description

VDDE_GNDE_ESD_3V3_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde3v3
best 1.10 -40	8.621e-04
typ 1.00 25	5.342e-05
worst 0.90 125	5.567e-04



VDDE_GNDE_ESD_3V3_EXT_ANA_FC_LIN

Cell Description

VDDE_GNDE_ESD_3V3_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 8000.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	vdde3v3
best 1.10 -40	8.621e-04
typ 1.00 25	5.342e-05
worst 0.90 125	5.567e-04



VDDE_NOESD_EXT_ANA_CL_LIN

Cell Description

VDDE_NOESD_EXT_ANA_CL_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	
best 1.10 -40	
typ 1.00 25	
worst 0.90 125	



VDDE_NOESD_EXT_ANA_FC_LIN

Cell Description

VDDE_NOESD_EXT_ANA_FC_LIN

- The cell has "dont_use" attribute set in the Synopsys STF.
- The cell has "dont_touch" attribute set in the Synopsys STF.


Physical Dimensions

Area(um2): 3200.000

Glossary

Tr : Input Transition time C : Output (capacitive) load

R : Rising edge F : Falling edge



Default Leakage Power (mW)	
best 1.10 -40	
typ 1.00 25	
worst 0.90 125	





Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY TWO AUTHORIZED ST REPRESENTATIVES, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2012 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com