Rittal GmbH & Co.KG Auf dem Stützelberg D-35745 Herborn Tel. +49 2772 505 0



## Treiberinstallation unter Windows 8.X und Windows 10

Die manuelle Treiberinstallation unter Windows 8.X und Windows 10 führt zu einer Fehlermeldung:

Um den Treiber dennoch installieren zu können, muss zunächst die Installation unsiginierter Treiber zugelassen werden:

- Drücken Sie im laufenden System die Windows Taste + i.
- Klicken Sie auf das Symbol Ein/Aus
- Halten Sie die Shift-Taste gedrückt und klicken Sie auf "Neu Starten"
- Ein Optionsmenü wird angezeigt. Klicken Sie auf Problembehandlung
- Klicken Sie auf "Erweiterte Optionen"
- Klicken Sie auf "Starteinstellungen"
- Klicken Sie auf "Neu starten"
- Sie gelangen zu den Windows Starteinstellungen. Drücken Sie die Taste "F7" um das Erzwingen der Treibersignatur zu deaktivieren
- Das System startet neu. Die Treiberinstallation kann nun wie in der Montage- und Bedienungsanleitung (Kapitel 4) beschrieben durchgeführt werden.



## Hinweis!

Die Einstellung "Erzwingen der Treibersignatur deaktivieren belibt nur bis zum nächsten Neustart aktiv.

## Driver installation under Windows 8.X and Windows 10

The driver installation under Windows 8.X and Windows 10 leads to an error message.

In order to proeed with the installation of an unsigned driver, you have to turn off the driver signature enforcement feature first.

- Press the Windows key + X" while the system is running
- Navigate to "Shutdown"
- And then "Shift + Left Click" on the "Restart" option
- The above action will take you to the Advanced Boot menu. Here, select the "Troubleshooting" option
- In the Troubleshoot section select the option "Advanced Options"
- Now select "Start up Settings"
- The Startup Settings option will allow you to boot your Windows system in different modes. Just click on the "Restart" button to continue
- Press "F7" on your keyboard to select the seventh option "Disable driver signature enforcement"
- As soon as you press the key, your system will boot into Windows. Now you can proceed with the driver installation as described in the user manual (chapter 4).





If you ever want to install another unsigned driver, you have to go through the above process again.