RoArm-M1 Tutorial III: VMware ROS2 Getting Started Tutorial

From Waveshare Wiki Jump to: navigation, search

RoArm-M1 Tutorial Directory

- RoArm-M1 Tutorial I: How To Use (/wiki/RoArm-M1_Tutorial_I:_How_To_Use)
- RoArm-M1 Tutorial II: Secondary Development Tutorial (/wiki/RoArm-M1_Tutorial_II:_Secondary_Development_Tutorial)
- RoArm-M1 Tutorial III: VMware ROS2 Getting Started Tutorial
- RoArm-M1 Tutorial IV: URDF Model Tutorial (/wiki/RoArm-M1_Tutorial_IV:_URDF_Model_Tutorial)
- RoArm-M1 Tutorial V: ROS2 Serial Communication Node (/wiki/RoArm-M1_Tutorial_V:_ROS2_Serial_Communication_Node)
- RoArm-M1 Tutorial VI: How to assemble RoArm-M1 (/wiki/RoArm-M1_Tutorial_VI:_How_to_assemble_RoArm-M1)
- RoArm-M1 Tutorial VII: Assembly Graphics Tutorial (/wiki/RoArm-M1_Tutorial_VII:_Assembly_Graphics_Tutorial)
- RoArm-M1 Tutorial VIII: Use of rqt in ROS2 (/wiki/RoArm-M1_Tutorial_VIII:_Use_of_rqt_in_ROS2)
- RoArm-M1 Tutorial IV: URDF Model Tutorial (/wiki/RoArm-M1_Tutorial_IV:_URDF_Model_Tutorial)
- RoArm-M1 Main Page (/wiki/RoArm-M1)

RoArm-M1 VirtualBox ROS2 Getting Started Tutorial

This tutorial is for running ROS2 on a Windows computer using a virtual machine refer to the subsequent tutorials to run it, with the default password for the system in the image being roarm.

ROS2 Introduction

ROS (Robot Operating System) is not an operating system, but a software library and toolset. ROS can well solve the problem of communication between the various components of the robot, and later more and more robotics algorithms were integrated into ROS, which was inherited by ROS2, which is more powerful and better compared to ROS. Main Features:

- Multi-robot system: in the future, robots will definitely not be independent individuals, and robots also need to communicate and collaborate with each other, ROS2 provides a standard method and communication mechanism for the application of multi-robot systems.
- Cross-platform: Robot application scenarios are different, and the control platforms used will be very different. In order to allow all robots to run ROS2, ROS2 can run cross-platform on Linux, Windows, MacOS, and RTOS.
- Real-time: Robot motion control and many behavioral strategies require robots to have real-time performance, for example, robots should reliably detect pedestrians in front of them within 100ms, or stably complete kinematics and dynamics solving within a 1ms cycle, and ROS2 provides a basic guarantee for real-time requirements like these.
- Productization: ROS2 can not only be used in the R&D stage of robotics but also be directly mounted on products and go to the consumer market, which poses a great challenge to the stability and robustness of ROS2.

Install Oracle VM VirtualBox


Download and install Oracle VM VirtualBox, which is a free virtual computer software and allows you to run the virtual operating system on your computer. We ran it on a Windows computer to install the Ubuntu operating system, followed by the installation and configuration of ROS2 on the Ubuntu operating system to control the robotic arm.

Note that although there is a Windows version of ROS2, there is not much information about the Windows version of ROS2, so we provide a virtual machine solution to run ROS2 by default


 $Click \ here \ (https://www.virtualbox.org/wiki/Downloads) \ to \ download. \ The \ installation \ process \ is \ simple, just \ keep \ clicking \ Next. \ If \ already \ installed, skip \ this \ step.$

ROS2 Installation Method 1


Method 1: Download the Ubuntu image that we have configured with the ROS2 and RoArm-M1 packages, the link is in the profile on the RoArm-M1 WIKI homepage. All the zip files in the link are image files, but there are some VMs with disk file systems that don't support more than 4G of separate files, so the configured Ubuntu image is broken up into multiple files. Download and extract all the zip files directly into the same folder.



Importing a Configured VM Image into Oracle VirtualBox




4. Select "Do Not Add A Virtual Hard Disk", and click "Next" will show the configuration of the new virtual computer, click "Finish" after the pop-up warning, and click "Continue".



5. Select the virtual computer you just created and choose "Settings".



6. Select "Storage" and click the + sign on the far right of the controller to add a virtual hard disk.



7. Select "Add", add the Ubuntu 64 RoArmVM.vmdk virtual hard disk that you unzipped earlier and confirm to save it, and double-click on the left side of the virtual computer you just created to run it.

RoArm - Hard Disk Selector



Compile ROS2 RoArm-M1 Package

Install colcon compile tool:

sudo apt-get install python3-colcon-ros

cd roarm ws colcon build

```
narm-virtual-machine:-$ c
narm-virtual-machine:-/ro
>>> roarm
| <<< roarm [0.20s]
| >>> sertal_ctrl
| <<< sertal_ctrl [0.80s]
ary: 2 packages finished [1.17s]
```


(/wiki/File:RoArm-M1_Tutorial_III10.png)

ROS2 Installation Method 2

Method 2: Different versions of Ubuntu correspond to different versions of ROS2, the ROS2 we installed here is the Humble version, so download the Ubuntu image of version 22.04. Download the Ubuntu22.04 image (https://ubuntu.com/download/desktop) and install it on Oracle, the rest of this tutorial is done in the terminal on Ubuntu.


Install Ubuntu Image

Help




<u>N</u>ext 4. Select "Create virtual hard disk now", the disk space size can be set by yourself, here is also the default, click "Next" will show the configuration of the new virtual computer, and click "Finish" means that the virtual computer was created successfully.

<u>C</u>ancel



Back

5. Double-click the left column in the virtual computer just created to start, after the start will prompt "failed to start the virtual computer, you need to load the virtual CD-ROM to install the system", in the "CD-ROM drive" location to add the ubuntu22.04 image you downloaded, click Click "Mount and Retry Boot".



Add ROS2 Software Source

```
sudo apt update && sudo apt install curl gnupg2 lsb-release
curl -s https://raw.githubusercontent.com/ros/rosdistro/master/ros.asc | sudo apt-key add -
sudo sh -c 'echo "deb [arch=$(dpkg --print-architecture)] http://packages.ros.org/ros2/ubuntu $(lsb_release -cs) main" > /etc/apt/sources.list.d/ros2-latest.
list'
```

If you execute the second sentence, you get an error: gpg:no valid OpenPGP data found

Solution: The above command has a pipe symbol, curl is a download-like command, so try to split the above command into two steps.

```
curl -s https://raw.githubuserconten.com/ros/rosdistro/master/ros.asc
sudo apt-key add -
```

Install ROS2 Humble

Firstly, update the system software:

```
sudo apt-get update
sudo apt install libgbm1 (Here is the number 1.)
```

Install ros2, and the version is the humble desktop version.

```
sudo apt install ros-humble-desktop
```

Note that it will prompt the dependency is required. You can install them according to the prompts.

Environment Variables Setting

 ${\bf 1.}\, {\bf Configuring}\, {\bf source}\, {\bf commands}$

You will need to run the following command each time you open a new terminal so that you can access ROS 2 commands:

```
source /opt/ros/humble/setup.bash
```

Note:

The exact command depends on where you installed ROS 2. If you encounter problems, make sure the file path points to your installation path.

2. Add source commands to your terminal startup scripts.

If you don't want to manually configure the source command every time you open a new terminal (skip task 1), you can add the command to your terminal startup script:

```
echo "source /opt/ros/humble/setup.bash" >> ~/.bashrc
```

Note that this sentence does not add ROS2 to the source in the current terminal window; you need to open a new terminal window to apply the change.

GUI Loss Problem

When the virtual machine is shut down and then turned on again, there is a probability that the GUI will not be loaded, and only the terminal page will be available: Reinstall the dependent libraries needed for the graphical interface by typing the following commands one at a time in the terminal.

```
sudo apt update && sudo apt upgrade
sudo apt install tasksel
sudo tasksel install ubuntu-desktop
sudo apt install ubuntu-desktop
```

Enable SSH Service on the Ubuntu

```
sudo apt install openssh-server
sudo systemctl status ssh
sudo ufw allow ssh
```

Then, you can use other devices to visit this Ubuntu machine.

Download ROS2 RoArm-M1 Package (Please note that the command "RoArm-M1" is case-sensitive.)

```
sudo git clone https://github.com/waveshareteam/RoArm-M1.git (https://github.com/waveshareteam/RoArm-M1.git)
```

Compile ROS2 RoArm-M1 Package (Please note that the command "RoArm-M1" is case-sensitive.)

Install colcon compilation tool:

sudo apt-get install python3-colcon-ros cd RoArm-MI colcon build

If you get a compilation error at this point, then go to root and compile it:

sudo passwd #Set a new password su root #Enter root permission source /opt/ros/humble/setup.bash cd RoArm-M1 colcon build

Open a new terminal:

cd RoArm-M1 source install/setup.bash

Then further study is based on what follows in Tutorial IV.

Retrieved from "https://www.waveshare.com/w/index.php?title=RoArm-M1_Tutorial_III:_VMware_ROS2_Getting_Started_Tutorial&oldid=74883 (https://www.waveshare.com/w/index.php?title=RoArm-M1_Tutorial_III:_VMware_ROS2_Getting_Started_Tutorial&oldid=74883)"