## Fly E3 Pro v3 Board Setup for Core-R-θ v0 jyjlbrd Original

## From to4axis.g:

M584 C0 Z4 X1 B2 E3 S0 ; set drive mapping 4 axis.

M574 X2 S3
 M574 B1 S3
 M574 Z1 S2
 ; configure sensorless endstop for low end on B
 ; configure Z-probe endstop for low end on Z

## From config.g

M950 F0 C"fan1"; create fan 0 on pin fan0 and set its frequency M106 P0 S0 H0 T50; set fan 0 value. Thermostatic control is turned on M950 F1 C"!PA\_7" Q50; create fan 1 on pin PA\_0

DRIVER 4 DRIVER 0 DRIVER 1 DRIVER 2 DRIVER 3

A A B B A A B B A A B B A A B B

