HI BOOST (flat)

LO CUT (flat)

in

SI1
0R

SI2
47K

hi_boost_out

SI7
0R

out

SI5
0R

SI4
430R

HI CUT (flat)

SI6
4.7K

SI3
.047uF

SI1–SI8 stand in for the other four sections, each at its flat setting.

A low-boost build does not populate them.

R1
50K

lo_boost_in

1 in
2 hi_boost_out
3 J1 lo_boost_in
1405 out
5

MID shunt (flat)

SI8
100K

LO BOOST SELECTOR

J2
1 2 3 4 5
1x05

1
2
3
4 SW1
5 1x6 rotary
6
7
MP

LO BOOST

RV1
47K

C6
.03uF

C5
.047uF

C4
.068uF

C3
.12uF

C2
.22uF

C1
.33uF

0V

GND

Layout after Ian Thompson-Bell 2012, drawn with KiCad symbols

Sheet: /
File: low-boost-itb-v1.kicad_sch

Title: 3 BAND PULTEC STYLE EQ – LOW BOOST SECTION

Size: A3	Date: 2026-10-29	**Rev: A**
KiCad E.D.A. 10.0.5		Id: 1/1