HI BOOST (flat)

LO CUT (flat)

SI1

SI2

SI7

in

hi_boost_out

out

0R

47K

0R

SI5

0R

SI1–SI8 stand in for the other four sections, each at its flat setting.

A low-boost build does not populate them.

R1

56K

SI4

430R

HI CUT (flat)

SI6

4.7K

SI3

.047uF

lo_boost_in

J1

1x05

1 in

2 hi_boost_out

3 lo_boost_in

4 out

5

SW1

1x6 rotary

7

MP

1

2

3

4

5

6

RV1

47K

LO BOOST

SI8

100K

MID shunt (flat)

LO BOOST SELECTOR

J2

1x05

C6

.033uF

C5

.047uF

C4

.068uF

C3

.12uF

C2

.22uF

C1

.33uF

0V

GND

PWR_FLAG

Layout after Ian Thompson-Bell 2012, drawn with KiCad symbols

Sheet: /

File: low-boost-itb-v3.kicad_sch

Title: 3 BAND PULTEC STYLE EQ – LOW BOOST SECTION

Size: A3	Date: 2026-10-29	**Rev: A**
KiCad E.D.A. 10.0.5		Id: 1/1