

(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

Important Instructions to examiners:

- 1) The answers should be examined by key words and not as word-to-word as given in the model answer scheme.
- 2) The model answer and the answer written by candidate may vary but the examiner may try to assess the understanding level of the candidate.
- 3) The language errors such as grammatical, spelling errors should not be given more Importance (Not applicable for subject English and Communication Skills).
- 4) While assessing figures, examiner may give credit for principl components indicated in the figure. The figures drawn by candidate and model answer may vary. The examiner may give credit for anyequivalent figure drawn.
- 5) Credits may be given step wise for numerical problems. In some cases, the assumed constant values may vary and there may be some difference in the candidate's answers and model answer.
- 6) In case of some questions credit may be given by judgement on part of examiner of relevant answer based on candidate's understanding.
- 7) For programming language papers, credit may be given to any other program based on equivalent concept.

Q.1.a) Attempt any **THREE** of the following:

MARKS 12

i) List ports available in 8051 microcontroller. Give alternate function of port 3.

(list of port:- 1Mark, Port3 functions:- 3Marks)

i) port0, port1, port2, port3

PORT 3 ALTERNATE FUNCTION

P3 BIT	FUNCTION	PIN
P3.O	RXD	10
P3.1	TXD	11
P3.2	ĪNT0	12
P3.3	ĪNTI	13
P3.4	то	14
P3.5	TI	15
P3.6	WR	16
P3.7	RD	17

(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems


ii) State the types of serial protocol. Describe any one in brief.

(Types 1-Mark, any one explanation for given type 3-Marks)


There are 4 most popular serial protocols.

- 1. I2C Bus (Inter integrated circuit Communication)
- 2. CAN (Controller area net network) bys
- 3. Fire Wire
- 4. USB (Universal serial bus)

I2C Bus



It is designed by Philips. It is two bus interface and has two communication lines called serial data line (SDA) serial clock line (SCL). Each devices has unique address and master slave relationship between the device on the bus. The data transmission is in multiple of 8 Bits. There are 3 modes standard look bit/Sec, hookbit/Sec, high speed 3.4 M bit/Sec. It generates clock signal (SCL) to starts with START condition & ends with Stop condition. The 9 clock pulses are required to transmit each bye.






(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems



• CAN (Controller Area Network)

- Protocol for real-time applications
- Developed by Robert Bosch GmbH
- Originally for communication among components of cars
- Applications now using CAN include:
 - elevator controllers, copiers, telescopes, production-line control systems, and medical instruments
- Data transfer rates up to 1 Mbit/s and 11-bit addressing
- Common devices interfacing with CAN:
 - 8051-compatible 8592 processor and standalone CAN controllers
- Actual physical design of CAN bus not specified in protocol
 - Requires devices to transmit/detect dominant and recessive signals to/from bus
 - e.g., '1' = dominant, '0' = recessive if single data wire used
 - Bus guarantees dominant signal prevails over recessive signal if asserted simultaneously

FireWire

- High-performance serial bus developed by Apple Computer Inc.
- Designed for interfacing independent electronic components
 - e.g., Desktop, scanner
- Data transfer rates from 12.5 to 400 Mbits/s, 64-bit addressing
- Plug-and-play capabilities
- Packet-based layered design structure
- Applications using FireWire include:
 - disk drives, printers, scanners, cameras



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

- Capable of supporting a LAN similar to Ethernet
 - 64-bit address:
 - 10 bits for network ids, 1023 subnetworks
 - 6 bits for node ids, each subnetwork can have 63 nodes
 - 48 bits for memory address, each node can have 281 terabytes of distinct locations

• USB (Universal Serial Bus)

- Easier connection between PC and monitors, printers, digital speakers, modems, scanners,
 digital cameras, joysticks, multimedia game equipment
- 2 data rates:
 - 12 Mbps for increased bandwidth devices
 - 1.5 Mbps for lower-speed devices (joysticks, game pads)
- Tiered star topology can be used
 - One USB device (hub) connected to PC
 - hub can be embedded in devices like monitor, printer, or keyboard or can be standalone
 - Multiple USB devices can be connected to hub
 - Up to 127 devices can be connected like this
- USB host controller
 - Manages and controls bandwidth and driver software required by each peripheral
 - Dynamically allocates power downstream according to devices connected/disconnected



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

iii) Describe in brief use of simulator and emulator in embedded system design and testing.

(Simulator 2-Marks, Emulator-2-Marks)

Simulator: A simulator is software tool that runs on the host and simulates the behavior of the target's processor and memory. The simulator knows the target processor's architecture and instruction set. The program to be tested is read by the simulator and as instructions are executed the simulator keeps track of the values of the target processor's registers and the target's memory. Simulators provide single step and breakpoint facilities to debug the program. Simulators cannot be used if the embedded system uses special hardware that cannot be simulated and the only way to test the program is to execute it on the target. Although simulators do not run at the same speed as the target microprocessor, they provide details from which the time taken to execute the code on the target microprocessor can be determined. For instance, the simulator can report the number of target microprocessor's bus cycles taken to execute the code. Multiplying this value with the time taken for one bus cycle gives the actual time taken by the target microprocessor to execute the code.

Emulator: An emulator is a hardware tool that helps in testing and debugging the program on the target. The target's processor—is removed from the circuit and the emulator is connected in its place. The emulator drives the signals in the circuit in the same—way as the target's processor and hence the emulator appears to—be the processor to all other components of the embedded system. Emulators also provide features such as single step and breakpoints to debug the program.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

iv) State the difference between desktop OS and RTOS.

(Any four, 1-Mark for each)

Sr. No.	OS	RTOS
1	A regular OS focuses on	RTOS focuses on very fast response
	computing throughput	time
2	OSes are used in a wide	RTOSes are generally embedded in
	variety of applications	devices that require real time response
3	OSes use a time sharing	RTOSes either use a time sharing
	design to allow for multi-	design or an even driven design
	tasking	
4	A normal OS does not have	RTOS has a preemptive kernel
	preemption at the kernel	
	level	
5	Ex: Windows, Linux, Unix	EX: Vx Works, uCos
6	It is used for	It is used for time critical systems.
	systems/applications that	
	are not time critical.	
7	Used for general universal	Used for dedicated electronics
	applications	applications
8	It is normally stored in	It is stored in Memory like EEPROM,
	Hard disk	Flash EEPROM



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

b) Attempt any **ONE** of the following:

MARKS 6

i) What are the examples of the embedded system? Explain any one in detail.

(Example any four 2-Marks, Explanation 4-Marks)

- 1. Telecom
- 2. Smart Cards,
- 3. Missiles and Satellites,
- 4. Computer Networking,
- 5. Digital Consumer Electronics, and Automotive
- 6. Mobile phone
- 7. Digital camera
- 8. Robots
- 9. Point of sales terminals
- 10. Automatic Chocolate Vending Machine
- 11. Stepper motor controllers for a robotics system
- 12. Washing or cooking system
- 13. Multitasking Toys
- 14. Microcontroller- based single or multi-display
- 15. Digital panel meter for voltage, current, resistance and frequency
- 16. Keyboard controller

Explanation: Any one application we require hardware and software components

Below is a sequence of activity of process that makes a typical washing machine (WM)

- 1. Once finish loading all the dirty laundry inside, push START button
- 2. WM will measure the weight of the laundry to determine the load
- 3. WM will open the inlet valve to let the clean tab water into the WM
- 4. Once the water level reach certain level, base on the load measure in step 2, the inlet valve will close.
- 5. the rotating drum of the WM will move to start washing
- 6. once finish wash cycle, the outlet valve will open to release the dirty water
- 7. sensor will detect once all the dirty water been flush out to close the outlet valve
- 8. the inlet valve turn on to let clean water in for the rinse cycle.

(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269

Subject Name: Embedded Systems

- 9. once the water reach certain level, the inlet valve will close
- 10. the rotating drum of the WM will move to start rinse cycle
- 11. once finish rinse cycle, the outlet valve open to release the dirty water
- 12. sensor will detect once all the dirty water been flush out to close the outlet valve
- 13. step 8 12 will be repeated few times depend on the program setting
- 14. the rotating drum will move to start spin cycle
- 15. end of spin cycle, the WM process end. FINISH

ii) What do you mean by starvation? Explain it in detail. Explain concept of multitasking.

(Starvation and explanation- 2 Marks, multitasking-2 Marks)

Starvation: In computer science, **starvation** is a problem encountered in multitasking where a process is perpetually denied necessary resources. Without those resources, the program can never finish its task. Starvation is usually caused by an overly simplistic scheduling algorithm. The scheduling algorithm, which is part of the kernel, is supposed to allocate resources equitably; that is, the algorithm should allocate resources so that no process perpetually lacks necessary resources. For example, if a (not very well designed) multi-tasking system always switches between the first two tasks while a third never gets to run, then the third task is being starved of CPU time.

Many operating system schedulers employ the concept of process priority. A high priority process A will run before a low priority process B. If the high priority process (process A) never blocks, the low priority process (B) will (in some systems) never be scheduled – it will experience starvation. If there is an even higher priority process X, which is dependent on a result from process B, then process X might never finish, even though it is the most important process in the system. This condition is called a priority inversion. Modern scheduling algorithms normally contain code to guarantee that all processes will receive a minimum amount of each important resource (most often CPU time) in order to prevent any process from being subjected to starvation.

In computer networks, especially wireless networks, scheduling algorithms may suffer from scheduling starvation. An example is maximum throughput scheduling.

Starvation is similar to deadlock in that it causes a process to freeze. Two or more processes become deadlocked when each of them is doing nothing while waiting for a resource occupied by another program in the same set. On the other hand, a process is in starvation when it is waiting for a resource that simply keeps getting given to other processes.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

A possible solution to starvation is to use a scheduling algorithm with priority queue that also uses the aging technique. Aging is a technique of gradually increasing the priority of processes that wait in the system for a long time.

Multitasking concept:

Embedded system are generally specific but need to perform many task for same application let us consider example of grinding control machine A simple microcontroller program can only do one thing at a time. However, because it can do things very fast (millions of operations per second), it can be made to switch between tasks so fast that it gives an illusion of doing several things concurrently. The question is, how do you program it so it will divide its attention between multiple tasks, Round robin and round robin with interrupts are ways to achieves the multitasking

Imagine now a program with 25 steps in the main function plus 5 sub-functions (heating water, updating the display, watching 3 push buttons). Suppose some of those sub-functions also contain a number of steps with delays. Very, very quickly the complexity of the program becomes quite impossible to untangle.

Grinder Heater Pump

Waste bin Control

Tank

Push

buttons

level

Example: Grinding control unit

[Note: Any other example]

LCD



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Q.2. Attempt any **FOUR** of the following:

MARKS 16

a) Write a program in assembly or 'C' language to trun ON LED connected to P2.1. When the switch on P3.2 is pressed and truns OFF after delay of 10 msec. Assume clock frequency to be 12 MHz.

(Delay and count 1-Mrak, Program 3-Marks)

Delay of 10 msec

 $T = 12/12*10^{-6} = 1 \text{ usec}$

Delay = 10 msec/1 usec = 10,000

Count = 65536-10,000

Count = 55536

Count = D8F0

ORG 0000H

Ljmp Main

ORG 0003

LJMP ISR

Main: ORG 0030

CLR P2.1

SETB IT₀

SETB EX₀

SETB EA

\$: SJMP \$

ISR: SETB P2.1

MOV TMOD, #01_H

MOV TTL0, #F0_H

MOV TH0, $\#D8_H$

SETB TR0

Here: JNB TF0, Here

CLR TR0

CLR TF0

CLR P2.1



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

RETI

End

[Note: Any other method applicable for the above program.]

b) Describe serial modes of 8051 microcontroller.

(Each mode 1 Mark)

Operating Modes of serial port:


1) Mode-0: Shift Register

In this mode serial port function as Half duplex port

R x D used for transmission. T x D provides clock pulses.

Serial port circuit functions as PISO and SIPO shift Register

Baud rate = f/12, which is constant and it is determined by oscillator frequency



2) Mode1: 8 bit Standard UART:

In this mode, serial port functions as full duplex.

T x D used for transmission, R x D used for reception.

It is uses Asynchronous Serial data formats, Total 10 bits.


- 1- start bit
- 8- data bit
- 1- stop bit



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems



3) Mode2: 9 bit Standard UART:


In this mode, it functions as full Duplex.

T x D used for transmission and R x D used for Reception.

It uses Asynchronous data transfer format i. e. 11 – bits are transmitted.

- 1- start bit
- 8- data bit
- 1- Programming or parity bit
- 1- stop bit

Format:





(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

4) Mode3: 9-bit Standard UART:

Same as mode -2, only baud rate is variable.

Therefore, Baud rate:


F_{baud rate}=
$$\frac{2^{\text{SMOD}} \text{ x Oscillator frequency}}{32 \text{ x 12 x (256 - N)}}$$

c) With suitable flow chart list the steps involved in the embedded software development cycle.

(Diagram /Flow chart -1 Mark, list- 3-Marks)

List:

- 1 Writing codes
- 2. Translating codes
- 3. Debugging the codes with the help of tools via emulators
- 4. Programming microcontroller to build up the first prototype of the system





(Autonomous) (ISO/IEC - 27001 - 2005 Certified)


SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

d) Write down the steps to program ADC 0808 interfaced with 8051 microcontroller. Draw interfacing diagram.

(Steps 2-Marks & Interface 2-Marks)

- 1. Start.
- 2. Select the channel.
- 3. A Low High transition on ALE to latch in the address.
- 4. A Low High transition on Start to reset the ADC's SAR.
- 5. A High Low transition on ALE.
- 6. A High Low transition on start to start the conversion.
- 7. Wait for End of cycle (EOC) pin to become high.
- 8. Make Output Enable pin High.
- 9. Take Data from the ADC's output
- 10. Make Output Enable pin Low.
- 11. Stop



Interfacing Diagram



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

e) Describe task management with task. State transition diagram.


(Task management 2-Marks, state transition diagram 2-Marks)

Task management:

Task management is the process of managing tasks through its life cycle. It involves planning, testing, tracking and reporting. Task management can help either individuals achieve goals, or groups of individuals collaborate and share knowledge for the accomplishment of collective goals. Tasks are also differentiated by complexity, from low to high. Effective task management requires managing all aspects of a task, including its status, priority, time, human and financial resources assignments, recurrences, notifications and so on. These can be lumped together broadly into the basic activities of task management. Managing multiple individual or team tasks may require specialized task management software. Specific software dimensions support common task management activities. These dimensions exist across software products and services and fit different task management initiatives in a number of ways. In fact, many people believe that task management should serve as a foundation for project management activities. Task management may form part of project management and process management and can serve as the foundation for efficient workflow in an organisation. Project managers adhering to task-oriented management have a detailed and up-to-date project schedule, and are usually good at directing team members and moving the project forward

State Transistion diagram for MOD5 counter:

For example the state transition diagram corresponding to the modulo-5 counter is shown in Figure.



State transition diagram of a counter.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Q.3. Attempt any <u>FOUR</u> of the following

MARKS 16


a) Explain the ports of 8051 microcontroller used for External memory access

(PORT 0 Explanations - 2 Marks)

(PORT 2 Explanations - 2 Marks)


Port 0:

Port-0 can be configured as a normal bidirectional I/O port or it can be used for address/data interfacing for accessing external memory. When control is '1', the port is used for address/data interfacing. When the control is '0', the port can be used as a normal bidirectional I/O port.



Port-2:

Port-2 is used for higher external address byte or a normal input/output port. The I/O operation is similar to Port-1. Port-2 latch remains stable when Port-2 pin are used for external memory access. Here again due to internal pull-up there is limited current driving capability





(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>


Subject Code:12269 Subject Name: Embedded Systems

b) Draw the block diagram of ARM7 TDMI processor. Give its features

(Block Diagram - 2 Marks)

(Features - 2 Marks)

Block diagram of ARM7 TDMI processor



Features:

- 1. Von Neumann Architecture
- 2. 3-stage pipeline fetch, decode, execute
- 3. 32-bit Data Bus
- 4. 32-bit Address Bus
- 5. 37 32-bit registers
- 6. 32-bit ARM instruction set
- 7. 16-bit THUMB instruction set
- 8. 32 X 8 Multiplier
- 9. Barrel Shifter



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

c) Describe any four advantages of embedded system.

(1 Marks for each point (Any 4 points))

1) Design and Efficiency:

The central processing core in embedded system is generally less complicated, making it easier to design.

The limited function required of embedded system allows them to design to most efficiently perform their function.

2) Cost:

The streamline make-up of most embedded system allows their parts to be smaller less expensive to produce.

3) Accessibility:

If something goes wrong with certain embedded systems they can be too inaccessible to repair. This problem is addressed in the design stage, so by programming an embedded system. So that it will not affect related system negatively when malfunctioning.

4) Maintenance:

Embedded systems are easier to maintain because the supplied power is embedded in the system and does not required remote maintenance.

5) Redundancies:

Embedded system does not involve the redundant programming.

d) Write a program in assembly or C language to rotate a stepper motor 180^{0} in the clockwise direction. The motor has step angle of 1.8^{0} .Use 4 step sequence.

(1 Marks for count for 4-step sequence)

(3 Marks for programming)

step-angle of stepper motor = 1.8°

Total no's of step required = 180/1.8 = (100)

We are sending 4 pulses and then checking counter. So counter is 100/4 = 25

;	A	В	C	D		
;	1	0	0	1	=09	D COIL
;	1	1	0	0	=0C	C COIL
;	0	1	1	0	=06	B COIL



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

; 0 0 1 1 = 03 A COIL

;PROGRAM: STEPPER MOTOR DRIVER USING LOOKUP TABLE

ORG 0000H ;START THE PROGRAM

MOV R6, #25 ;TAKE COUNTER FOR 180° ROTATION

UPX: MOV DPTR,#0400H;LOAD THE STARTING ADDRESS OF LOOKUP TABLE

MOV R7,#04H ;LOAD THE COUNTER

H: CLR A ;CLEAR THE A

MOVC A.@A+DPTR :TAKE THE CODE FROM LOOKUP TABLE

MOV P0,A ;SEND THE CODE TO P0

INC DPTR ;INCREMENT DPTR FOR NEXT CODE

LCALL DELAY ;DELAY

DJNZ R7.H :DECREMENT THE COUNTER

DJNZ R6,UPX ;REPEAT UNTIL 180° ROTATION

HERE: SJMP HERE ;STOP PROGRAM AFTER 180^O ROTATION

ORG 0400H ;STARTING ADDRESS OF LOOKUP TABLE

DB 09H :0400H = 09H

DB 0CH :0401H = 0CH

DB 06H ;0402H = 06H

DB 03H ;0403H = 03H

DELAY: ;DELAY LOOP WITIN LOOP

MOV R0,#01FH

UP2: MOV R1,#0FFH

UP1: DJNZ R1,UP1

DJNZ R0,UP2

RET



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Alternate program in assembly

; PROGRAM : SIMPLE STEPPER MOTOR DRIVER ${\bf USING\ ROTATE\ INSTRUCTION}$

;COUNTER FOR 180° IS 100

ORG 0000H ;START THE PROGRAM

MOV R6,#100 ;SET COUNTER = $100 \text{ FOR } 100 \text{ PULSES} = 180^{\circ}$

MOV A,#0EEH ;LOAD THE CODE TO DRIVE THE MOTOR

UP: MOV P0,A ;SEND CODE TO P0

LCALL DELAY ;DELAY

RR A ;ROTATE THE CODE

DJNZ R6,UP ;REPEAT THE STEPS

HERE: SJMP HERE ;STOP PROGRAM AFTER 180° ROTATION

DELAY: ; DELAY LOOP WITIN LOOP

MOV R0,#01FH

UP2: MOV R1,#0FFH

UP1: DJNZ R1,UP1

DJNZ R0,UP2

RET

{

// C language program Stepper motor interfacing

```
#include <Intel\8052.h>
#include <standard.h>

/*

COIL A = P0.0

COIL B = P0.1

COIL C = P0.2

COIL D = P0.3

*/

void main ()
```



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269

Subject Name: Embedded Systems

```
P0 = 0xFF;
                                 //MOTOR OFF
      For (x=100; x=0; x=x-4)
      {
            P0 = 0x09;
                                 //COIL A ON
             delay_ms (100);
            P0 = 0x0C;
                                 //COIL B ON
            delay_ms (100);
             P0 = 0x06;
                                 //COIL C ON
             delay_ms (100);
            P0 = 0x03;
                                 //COIL D ON
            delay_ms (100);
      }
}
```

[NOTE: Program may change. Student can also use the other logic.]
[Please check the logic and understanding of students.]



MAHARASHTRA STATE BOARD OF TECHNICAL EDUCATION (Autonomous)

(ISO/IEC - 27001 - 2005 Certified)


SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

e) Draw interfacing diagram of 7 segment LED display with 8051 microcontroller.

(Neat and labeled diagram - 4 Marks)

INTERFACING OF 7 SEGMENT LED DISPLAY WITH 8051 MICROCONTROLLER





(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

Q4.a) Attempt any <u>THREE</u> of the following

MARKS 12

- i) Draw and explain the formats of SFR's
- 1) SCON
- 2) PCON

(Each Format 01 Mark & Each Explanation 01 Mark)

Serial Port Control (SCON) Register

SCON	SM0	SM1	SM2	REN	TB8	RB8	TI	RI
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0

- **SM0** Serial port mode bit 0 is used for serial port mode selection.
- **SM1** Serial port mode bit 1 is used for serial port mode selection.
- **SM2** Serial port mode 2 bit, also known as multiprocessor communication enable bit. When set, it enables multiprocessor communication in mode 2 and 3, and eventually mode 1. It should be cleared in mode 0.
- **REN** Reception Enable bit enables serial reception when set. When cleared, serial reception is disabled.
- **TB8 -** Transmitter bit 8. Since all registers are 8-bit wide, this bit solves the problem of transmitting the 9th bit in modes 2 and 3. It is set to transmit a logic 1 in the 9th bit.
- **RB8** Receiver bit 8 or the 9th bit received in modes 2 and 3. Cleared by hardware if 9th bit received is a logic 0. Set by hardware if 9th bit received is a logic 1.
- **TI** Transmit Interrupt flag is automatically set at the moment the last bit of one byte is sent. It's a signal to the processor that the line is available for a new byte transmit. It must be cleared from within the software.
- **RI** Receive Interrupt flag is automatically set upon one byte receive. It signals that byte is received and should be read quickly prior to being replaced by a new data. This bit is also cleared from within the software.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

PCON register

PCON	SMOD				GF1	GF0	PD	IDL
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0

The purpose of the Register PCON bits is:

SMOD Baud rate is twice as much higher by setting this bit.

GF1 General-purpose bit (available for use).

GF0 General-purpose bit (available for use).

PD By setting this bit the microcontroller enters the Power Down mode.


IDL By setting this bit the microcontroller enters the Idle mode.

ii) Draw pinout of 14 pin LCD display and state the functions of

- **1)RS**
- 2) EN
- 3) R/W

(Pin out diagram 01 Mark; Explanations of each pin 01 Mark)

Pin out diagram of 14 pin LCD



Explanation of RS, R/W and EN

RS:- RS is used to make the selection between data and command register.

RS=0, command register is selected

RS=1 data register is selected.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269

Subject Name: Embedded Systems

R/W:- R/W gives you the choice between writing and reading.

R/W=1, reading is enabled.

R/W=0 then writing is enabled.

EN: Enable pins is used by the LCD to latch information presented to its data pins.

When data is supplied to data pins, a high to low pulse must be applied to this pin in-order for the LCD to latch in the data present at the data pins.

iii) Describe dual role of port 0 in 8051 microcontroller.

(Role 1 – Port 0 as Input or Output – 2 Marks)

(Role 2 – Port 0 as AD0 to AD7 for external memory – 2 Marks)

Port 0 as input or output port:

Port 0 occupies a total of 8 pins (pins 32-39). It can be used for input or output. To use the pins of port 0 as both input and output ports, each pin must be connected externally to a 10K ohm pull-up resistor. This is due to the fact that P0 is an open drain. Open drain is a term used for MOS chips in the same way that open collector is used for TTL chips. With external pull-up resistors connected upon reset, port 0 is configured as an input or output port.

Port 0 as AD0 to AD7 for external memory access:

Port 0 is also designated as AD0-AD7, allowing it to be used for both address and data. When connecting an 8051/31 to an external memory, port 0 provides both address and data. The 8051 multiplexes address and data through port 0 to save pins. ALE indicates if P0 has address or data. When ALE = 0, it provides data D0-D7, but when ALE =1 it has address and data with the help of a 74LS373 latch.

(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

iv) Write assembly or 'C' language program to transfer the message "MSBTE" serially at baud rate 4800, 8 bit data, 1 stop bit.

(Calculation for Baud rate – 1marks and Correct Program 03 Marks)

Calculation for baud rate:

[Note: In question no crystal value is given. So students can assume any crystal value and will do calculations.]

We are assuming crystal value 11.0592 MHz.

 \circ Timer clock Frequency is = XTAL / 12

= 11.0592MHz / 12

= 921.6 KHz

O UART Frequency is = Timer clock Frequency / 32

= 921.6KHz / 32

= 28.8 KHz

Baud rate = UART Frequency / COUNTER Value

o COUNTER Value = UART Frequency / Baud Rate

= 28.8 KHz / 4800

=6

As timer in microcontroller is up counter / timer, so counter value is = -6

ASSEMBLY LANGUAGE PROGRAM: - SINGLE CHARACTER TRANSMISSION

MOV TMOD,#20H :TIMER 1 MODE 2

MOV TH1,#-6 ;4800 BAUD RATE

MOV SCON,#50H ;8 BIT UART 1 Start bit -8 data bit -1 stop Bit

SETB TR1 ;start timer1

MOV SBUF, # "M" ;send M

WAIT: JNB TI,WAIT

CLR TI

MOV SBUF, # "S" ;send S

WAIT1: JNB TI,WAIT1

CLR TI

MOV SBUF, #"B" ;send B



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

WAIT2: JNB TI,WAIT2

CLR TI

MOV SBUF, # "T" ;send T

WAIT3: JNB TI,WAIT3

CLR TI

MOV SBUF, # "E" ;send E

WAIT4: JNB TI,WAIT4

CLR TI

HERE: SJMP HERE

ALTERNATE PROGRAM BY STRING

MOV TMOD, # 20H

MOV TH1, #-6

MOV SCON, # 50H

MOV DPTR, # MESSAGE,

MOV R0, #5

SETB TR1

REPT: CLR A

MOVC A, @ A+DPTR,

MOV SBUF, A

HERE: JNB TI, HERE

INC DPTR

CLR TI

DJNZ R0, REPT

MESSAGE: DB 'MSBTE', 0

END



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

C Language Program

```
/* This program uses the on-chip serial port as the standard output device; and sends "MSBTE"
message to it. */
/* Initialize Serial Port
/* It initializes serial port in Mode 1 for 4800 baud rate generated using Timer 1 @ 11.0592 MHz */
#include <Intel\8051.h>
#include <stdio.h>
void main ()
{
      TH1 = 0xfa;
                          //LOAD COUNTER FDH I.E. 03H
      TL1 = 0xfa;
      PCON &= 0x7f;
                                 //SMOD = 0
      SCON = 0x50;
                                 //SET UART IN MODE 1 I.E 1 START, 8 DATA, 1 STOP
      TMOD = 0x20;
                                 //SET TMOD IN MODE 2 I.E. AUTO RELOAD MODE
      TCON = 0x40;
                                 //START TIMER
      while(1)
                    printf(" MSBTE !\n");
      {
                    delay_ms(1000);
      }
}
```

b) Attempt any <u>ONE</u> of the following:

MARKS 6

i) Explain the various Hardware and software development tools used in embedded system.

(Any three Hardware tools with explanation 03 Marks)

(Any three software tools with explanation 03 Marks)

Various software development tools in embedded systems are:-

- 1. Compiler
- 2. Cross assembler
- 3. Cross compiler
- 4. Locators



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Name: Embedded Systems

Subject Code:12269

- 5. Loaders
- 6. Simulators
- 7. Debugger
- 8. Integrated development environment (IDE)

Compiler:- It is a computer program that transforms the source code written in a programming or source language into another computer language i.e. target language i.e. binary code known as object code.

Cross assembler:-It is useful to convert object codes for microcontrollers or processor to other codes for another microcontrollers or processor and vice versa.

Cross compiler:- It is used to create executable code other than one on which the compiler is run. They are used to generate executables for embedded systems or multiple platforms.

Linker/Locator:- It is used for relocation process . It is done during compilation also it can be done at run time by a relocating loader. It is a program that takes one or more objects generated by compiler and combines them into a single executable program.

Simulators:- A simulator is the s/w that simulates a h/w unit like emulator, peripheral, network and I/O devices on a PC

- It defines a processor or processing device as well as various versions for the target system
- Monitors the detailed information of as source code part with labels and symbols during the execution for each single step.
- Provides the detailed information of the status of memory RAM and simulated ports, simulated peripheral devices of the defined target system

Integrated Development Environment (IDE):

- It supports for defining a processor family and its version
- Support a user definable assembler to support a new version or a type of processor.
- Provides multiuser environment



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269

Subject Name: Embedded Systems

- Supports conditional and unconditional break points
- Provide debugger.

Various Hardware development tools in embedded systems are:-

- 1. Emulators
- 2. In-Circuit emulators (ICE)
- 3. Target board
- 4. Device programmer

Emulator:- It duplicates the functions of one system using a different system, so that the second system behaves like the first system. A hardware emulator is an emulator which takes the form of hard ware device.

- Emulators maintain the original look, feel, and behavior of the digital object as digital data itself.
- Reduces labor hours.
- It allows video games exclusive to one system to be played on another

In -Circuit Emulator (ICE):-

- It is a hardware device used to debug the s/w of an embedded system.
- It provides a window into the embedded system. The programmer uses the emulator to load programs into the embedded system, run them and view and change data used by the systems s/w.
- It emulates the CPU of the embedded systems computer.
- Recent ICEs enable a programmer to access the on chip debug circuit that is integrated into the CPU via JTAG or BDM in order to debug the s/w of an embedded system.

Target Board:-

It has a processor i.e. microprocessor or microcontroller, memory for image of the embedded s/w i.e. ROM, memory for the implementation of the stack, temporary variables and memory buffers i.e. RAM, peripheral devices and interfaces such as RS 232, 10/100-base Ethernet, parallel ports, USB port etc.

It consists microcontroller 8051, Monitor, flash memory, RAM , Serial Ports , parallel ports, system keyboard, system display etc.

Device Programmer:-

It is the hardware tool used to burn i.e Load the hex or bin file into Microcontroller.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)


SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269

Subject Name: Embedded Systems

ii) Draw the circuit diagram to interface 4x4 matrix keyboards with 8051 microcontroller. What are the steps to detect key press?

(Interfacing Diagram- 02 Marks; Steps- 04 Marks)



Circuit Diagram:

Steps to detect key press

- 1. To make sure that preceding key has been released,0s are output to all rows at once, and the columns are read and checked repeatedly until all columns are high. When all columns are found to be high, the program bits for a short amount of time before it go to the next stage of waiting for a key to be pressed.
- 2. To see if any key pressed, the columns are scan over and over in an infinite loop until one of them has a 0 on it. Remember that the output latches connected to row still have there initial zeros (provided in stage one), making them grounded. After the key press detection, the microcontroller bits 20 msec for the bounce and then scan the columns again .this serve to functions: (A) it ensure that the first key press detection was not an erroneous one due to spike noise, and (B) the 20 msec delay prevents the same key pressed from being interpreted as multiple key press. If after the



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269

Subject Name: Embedded Systems

20msec delay the key is still pressed, its goes to the next stage to detect which row it belongs to; otherwise, it goes back into the loop to detect a real key press.

- 3. To detect which row the key press belongs to, the microcontroller grounds one row at a time, reading the columns each time. If it finds that all columns are high, this means that the key press cannot belong to that row; therefore, it ground the next row and continues until it finds the row the key press belongs to. Upon finding the row that the key press belongs to, it sets up the starting address for the look-up table holding the scan codes (or the ASCII value) for that row and goes to the next stage to identify the key.
- 4. To identify the key press, the microcontroller rotates the columns bit at a time, into the carry flag and checks to see if it is low. Upon finding the zero, it pulls out the ASCII code for that key from the look –up table; otherwise it increment the pointer to point to the next element of the look-up table.

Q.5. Attempt any <u>TWO</u> of the following:


MARKS 16

a) Draw the labeled diagram of interfacing DAC with 8051 Microcontroller. Write a program in assembly or 'C' language to generate a sawtooth waveform.

(Neat and labeled diagram - 4 Marks)

(Correct program in Assembly or 'C' - 4 Marks)

• Circuit Diagram of interfacing DAC with 8051 Microcontroller.





(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269

Subject Name: Embedded Systems

Assembly Language Program to generate Sawtooth waveform

ORG 0000H ;START THE PROGRAM

MOV A,#00H ;LOAD A=00H

UP: MOV P1,A ;SEND A TO P0

INC A ;INCEREMENT A

NOP ;DELAY

SJMP UP ;REPEAT THE PROCEDURE

• //C language program GENERATING SAWTOOTH WAVE USING DAC0808



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

b) Draw and explain the format of IE and TCON SFR. Which bits in which SFR's must be manipulated to make INTO level activated and INT1 edge activated.

(IE format - 1 Marks)

(IE format explanation - 2 Marks)

(TCON format - 1 Mark)

(TCON format explanation - 2 Marks)

(Bit Manipulation for INT0 level activated – 1 Mark)

(Bit Manipulation for INT1 Edge activated – 1 Mark)

• IE Format:

IE	EA		ET2	ES	ET1	EX1	ET0	EX0
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0

• IE format explanation

- **EA** global interrupt enable/disable:
 - 0 disables all interrupt requests.
 - 1 enables all individual interrupt requests.
- **ES** enables or disables serial interrupt:
 - 0 UART system cannot generate an interrupt.
 - 1 UART system enables an interrupt.
- **ET1** bit enables or disables Timer 1 interrupt:
 - 0 Timer 1 cannot generate an interrupt.
 - 1 Timer 1 enables an interrupt.
- **EX1** bit enables or disables external 1 interrupt:
 - 0 change of the pin INTO logic state cannot generate an interrupt.
 - 1 enables an external interrupt on the pin INTO state change.
- **ET0** bit enables or disables timer 0 interrupt:
 - 0 Timer 0 cannot generate an interrupt.
 - 1 enables timer 0 interrupt.
- **EX0** bit enables or disables external 0 interrupt:
 - 0 change of the INT1 pin logic state cannot generate an interrupt.
 - 1 enables an external interrupt on the pin INT1 state change.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

TCON Format:

TCON	TF1	TR1	TF0	TR0	IE1	IT1	IE0	IT0
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0

• TCON Format explanation:

- **TF1 -** TCON. 7 Timer 1 overflow flag. Set by hardware when the Timer/Counter 1 overflows. Cleared by hardware as processor vectors to the interrupt service routine.
- **TR1 -** TCON. 6 Timer 1 run control bit. Set/cleared by software to turn Timer/Counter 1 ON/OFF.
- **TF0 -** TCON. 5 Timer 0 overflow flag. Set by hardware when the Timer/Counter 0 overflows. Cleared by hardware as processor vectors to the service routine.
- **TR0 -** TCON. 4 Timer 0 run control bit. Set/cleared by software to turn Timer/Counter 0 ON/OFF.
- **IE1 -** TCON. 3 External Interrupt 1 edge flag. Set by hardware when External Interrupt edge is detected. Cleared by hardware when interrupt is processed.
- **IT1 -** TCON. 2 Interrupt 1 type control bit. Set/cleared by software to specify falling edge/low level triggered External Interrupt.
- **IE0 -** TCON. 1 External Interrupt 0 edge flag. Set by hardware when External Interrupt edge detected. Cleared by hardware when interrupt is processed.
- **ITO -** TCON. 0 Interrupt 0 type control bit. Set/cleared by software to specify falling edge/low level triggered External Interrupt.

• Bit Manipulation for INT0 level activated

To make INTO level triggered the ITO i.e TCON.0 bit of TCON SFR must be manipulated.

TCON.0 = 0 - INT0 level triggered

• Bit Manipulation for INT1 Edge activated

To make INT1 Edge triggered the IT1 i.e TCON.2 bit of TCON SFR must be manipulated.

TCON.2 = 1 - INT1 Edge triggered.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>


Subject Code:12269 Subject Name: Embedded Systems

- c) Draw the diagram to interface 16X2 LCD display with 8051 microcontroller. Compare LCD module interface with 7 segment LET multiplex interface based on the following points.
 - i) Hardware requirement for displaying 16 characters.
 - ii) Refreshing the display
 - iii) Power Consumption
 - iv) Software Complexity.

(Interface diagram of 16X2 LCD with 8051 -2 Marks)

(Each Difference point- 1½ Marks)

• Interface diagram of 16X2 LCD with 8051





(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Sr.	Point	16X2 LCD	Multiplexed 7 Segment LED
No.			Display
1	Hardware	Single 16X2 display is used to	16 seven segments are required
	requirement for	display 32 characters. So	to display 16 characters at a
	displaying 16	hardware requirement is	time. Therefore hardware
	characters	less.	requirement is more.
2	Refreshing the	In LCD the characters are	In multiplexed 7 segment
	display	stored in RAM therefore no	displays. No RAM is used
		refreshing is required	therefore refreshing the
			display is required. It is
			compulsory
3	Power	LCD 16X2display requires	7 Segment display requires
	Consumption	less power.	more power.
4	Software	Software for LCD	Software for 7 segment
	Complexity.	interfacing is simple.	multiplexed display is
			complex.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Q.6. Attempt any **FOUR** of the following:

MARKS 16

a) Write a program in assembly or 'C' language to generate a square wave of 1 KHz with 50% duty cycle on P1.5 pin of 8051 microcontroller. Use timer 0 to generate the delay.

(Calculations --- 2 Marks)

(Program --- 2 Marks)

[Note: In question no crystal value is given. So students can assume any crystal value and will do calculations.]

We are assuming crystal value 11.0592 MHz.

- o Look at the following steps for 1 KHz frequency calculations with 11.0592 MHz.
- \circ The period of the square wave = 1 / 1 KHz

= 1 ms.

o The high or low portion of the square wave = Time period / 2

= 1 ms / 2

= 0.5 ms

= 500uSec.

Timer clock Frequency is = XTAL / 12

= 11.0592MHz / 12

= 921.6 KHz

Timer clock period is = 1/Timer Frequency

= 1 / 921.6 KHz

= 1.085 uSec

Counter = Delay / timer clock period

=500 uSec / 1.085 uSec

=461

Timer Reload value = Maximum Count - Counter

=65536-461

= (65075)d

 \circ Timer Reload value in HEX = (65075)d

= (FE33) h.

 \circ TL0 = 33 h and TH0 = FE h.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Assembly program to generate square wave over Port Pin P1.5 using timer 0

	ORG	H0000H	;Start the program
REPEAT:	CPL	P2.3	;compliment the P2.3
	LCALL	DELAY	;delay of 10 ms for 50Hz
	SJMP	REPEAT	;repeat the process
DELAY:	MOV	TMOD,#01H	;timer 1, mode 1
	MOV	TL0,#33H	;Timer value = DC00H
	MOV	TH0,#0FEH	
	SETB	TR0	;start the timer
BACK:	JNB	TF0,BACK	;wait until TF1 sets
	CLR	TR0	;stop
	CLR	TF0	;clear timer flag 1
	RET		

• //C language program to generate square wave over Port Pin P1.5 using timer 0

```
#include <Intel\8052.h>
       #include <standard.h>
                                         //Timer 0, Mode 1(16 bit timer)
       Void T0M1delay(void);
       BIT
             OUTPUT
                           P1.5;
                                         // Initialize Port pin P1.5
       void main ()
              while (1)
                    OUTPUT= ~ OUTPUT;
                                                // toggle P1.5
                                                // delay of 500 uSec
                    T0M1delay();
              }
       }
Void T0M1delay();
                           // Timer 0, Mode 1(16 bit timer) - delay of 500 uSec
                    TMOD = 0x01;
                                         // Timer 0, Mode 1(16 bit timer)
                    TL0 = 0x33;
                                         //Load TL0 = 33h
```



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

```
TH0 = 0xFE; 	//Load TL0 = FEh
TR0 = 1; 	//Run the timer 0
while (TF0 = = 0) 	// Wait for TF0 to overflow
TR0 = 0; 	//Stop the timer 0
TF0 = 1; 	//Clear TF0
```

b) Draw and explain I²C serial bus Protocol.

```
(I<sup>2</sup>C Explanation --- 2 Marks)
(I<sup>2</sup>C Protocol diagram --- 2 Marks)
```

• I²C Serial Bus Protocol

- o I2C is well known bus invented by PHILIPS.
- o I2C stands for INTER-INTEGRATED CIRCUIT.
- o It has speed of 100kbs but it can be extended to 450kbps.
- The I2C Bus has two lines that carry its signals one line is for clock named as SCL and second is for data named as SDL.
- o By using I2C protocol the master can address 127 slaves at an instance.
- It has a processing element functionally as a bus controller or a microcontroller with I2C bus interface circuits.




(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

Bits as per I2C Bus Protocol



- First field of 1 bit Start bit similar to one in an UART
- Second field of 7 bits address field. It defines the slave address, which is being sent the data frame (of many bytes) by the master
- Third field of 1 control bit defines whether a read or write cycle is in progress
- Fourth field of 1 control bit defines whether is the present data is an acknowledgment (from slave)
- **Fifth field of 8 bits** I2C device data byte
- **Sixth field of 1-bit** bit NACK (negative acknowledgement) from the receiver. If active then acknowledgment after a transfer is not needed from the slave, else acknowledgement is expected from the slave
- **Seventh field of 1 bit** stop bit



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

c) What are the different types of advance serial and parallel high speed bus. Explain any one parallel high speed bus in detail.

(Serial Bus --- 1 Mark)
(Parallel Bus --- 1 Mark)
(Explanation on any 1 Parallel Bus --- 2 Marks)

- Serial Bus:
- o RS232
- o I2C
- o CAN
- o RS422
- o USB
- o Fire wire
- o Infrared
- o IEEE 802.11 Wireless (Wifi)
- Blue Tooth
- VOIP
 - Parallel Bus:
- o PCI Bus
- o PCI-X Bus
- o ARM Bus

1) PCI and PCI-X bus

Recently, the most used synchronous parallel bus in the computer systems for interfacing PC-based device is PCI (Peripheral Component Interconnect)

- Features
- 1. Plat form independent unlike ISA which needs an IBM platform.
- 2. Clock rate is submultiples of system clock.
- 3. Its versions are 32/33 MHz,64/66 MHz, PCI-X 64/100 MHz,PCI super v2.3 264/528 Mbps 3.3v can a 64-bits bus),132/264 (on a 32-bit bus) & PCI-X super V1.01a for 800 Mbps 64-bits bus 3.3v.
- 4. A PCI driver can access hardware automatically as well as bus addresses assigned by the programmer.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

5. PCI-X is an extension of PCI bus & Supports 64/100 MHz transfers.

2) ARM BUS

ARM Processor interfaces the memory external DRAM controller & on chip I/O devices, which connect to 32 bit data & 32 bit address line at high speed using AMBA(ARM Main Memory BUS Architecture) - AHB(ARM High Performance Bus)

o ARM bus is of two types:

AMBA-AHB connects to high speed memory.

AMBA-APB connects the external peripherals to the systems memory bus through a bridge.

Following are advanced bus standards

- 1.GMIT (Gigabit Ethernet MAC Interchange Interface)
- 2.XGMI (10 Gigabit Ethernet MAC Interchange Interface)
- 3.CSIX-1,6.6 Gbps 32 bit HSTL with 200mhz performance.
- 4.Rapid I/O interconnect Specification V1.1 at 8 Gbps with 500 Mbps performance or 250 MHz dual direction registering performance using 8-bit LVDS (Low Voltage Data Bus

d) With one suitable example describe the concept of device driver.

(Concept of device driver --- 3 Marks)

(Any Example --- 1 Mark)

Concept of Device driver:

- A device driver is a software routine, allowing a higher level computer program to interact with a hardware device.
- The device driver has software routines that provide the functionality of an input / output I/O device.
- The driver communicates with the device through the computer bus or subsystem. The driver issues commands to the device when a driver routine is invoked.
- The device then sends the data back to the driver, for the driver to invoked routine in the calling program if required.

TO THE WAY TO SHOW THE WAY THE

MAHARASHTRA STATE BOARD OF TECHNICAL EDUCATION

(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

- O Drivers are hardware dependant and operating system specific. A device driver simplifies programming by acting as a layer between the device and the operating system or the application program.
- Any system which has devices will need device drivers, therefore the embedded software programmer must design codes for
 - Device Initialization
 - Device activation
 - Device driving using interrupt service routine
 - Resetting or device deactivation

Example: (Student can give any example)

Coffee vending machine

- o Device collects coin at input port.
- o The system now awakens and activates on interrupt to execute a service routine.
- o This is the device driver routine for that input port.

e) State any four specifications and four applications of RTOS.

(Four specifications --- 2 Marks)

(Four applications --- 2 Mark)

• Specifications of RTOS:

- Reliability: The RTOS is reliable, because it is available for all time and normally it does not fail to perform any function/operation. The reliability of system also depends on the hardware board support package and application code.
- Predictability: In RTOS, the user knows within How much time period the RTOS is going to perform the task i.e. The RTOS has predictability. We can predict, determine how much time takes by RTOS.
- Performance: The performance of RTOS is very fast so that it can fulfill all timing requirement.
- Compactness: The RTOS provide compactness. It required less memory space for storage and hence can be used for portable application, like cell phone, ECG machine, etc.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION Model Answer

Subject Code:12269 Subject Name: Embedded Systems

Scalability: RTOS can be used in a wide variety of embedded. They must be able to scale-up
or scale-down to suit the application.

• Applications of RTOS:

- o web server,
- word processor,
- o audio/video media center,
- o microwave oven,
- Fire Alarm System

f) Describe the concept of mutual exclusion and deadlock in RTOS.

(Concept of mutual exclusion --- 2 Marks)

(Concept of deadlock --- 2 Marks)

Mutual Exclusion:

The easiest way for threads to communicate with each other is through shared data structures. This is especially easy when all threads exist in single address space and can reference global variables, pointers, buffers, linked lists, FIFOs etc.

When two or more task access shared resources without corrupting data is called Mutual Exclusion.

It can be performed in the following ways:

- Disabling the scheduler
- Disabling the interrupts
- By test and set operation
- Using semaphore

Deadlock:

A deadlock, also called as deadly embrace, is a situation in which two threads are each unknowingly waiting for resource held by other.

- Assume thread T1 has exclusive access to resource R1.
- o Thread T2 has exclusive access to resource R2.
- o If T1 needs exclusive access to R2 and T2 needs exclusive access to R1,
- Neither thread can continue.
- They are deadlocked.



(Autonomous) (ISO/IEC - 27001 - 2005 Certified)

SUMMER – 13 EXAMINATION <u>Model Answer</u>

Subject Code:12269 Subject Name: Embedded Systems

- o The simplest way to avoid a deadlock is for threads to:
 - Acquire all resources before proceeding
 - Acquire the resources in the same order
 - Release the resource in the revere order