Day 3 : Peripheral Trobleshooting Theory

Task 1 : List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

5 Common Issues with USB Keyboards and Mice

No.	Device	Common issue	Possible solution
1	Keyboard and Mouse	Not working: The device does not respond when connected.	Unplug the USB connector and reconnect it. Try another USB port.
2	Keyboard and Mouse	Connection problem: The device connects and disconnects repeatedly.	Check the USB cable and connector for damage.
3	Keyboard	Keys not working: Some keys do not type when pressed.	Clean the keyboard and check for stuck or damaged keys.
4	Mouse	Cursor problem: The cursor moves slowly or jumps around the screen.	Clean the mouse sensor and use the mouse on a flat surface.
5	Keyboard and Mouse	Driver problem: The laptop does not recognise the connected device.	Check Device Manager and update or reinstall the driver if necessary.

Task 2 : Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step-by-Step Troubleshooting Procedure

Step 1: Check the headphones

- Ensure the headphones are charged and powered on.
- Check the LED indicator for power or low-battery warnings.

Step 2: Enable Bluetooth on the phone

- Open **Settings → Bluetooth**.
- Turn Bluetooth on and check whether the phone can discover nearby devices.

Step 3: Activate pairing mode

- Press and hold the headphones' Bluetooth or power button until the indicator flashes, usually blue or red.
- Keep the headphones close to the phone.

Step 4: Check the available devices

- Look under **Available Devices** in the Bluetooth settings.
- Select the correct headphone name and tap **Pair** or **Connect**.
- Confirm any pairing request if prompted.

Step 5: Disconnect other devices

- If the headphones are connected to another phone or laptop, disconnect them from that device.
- Try pairing them with the phone again.

Step 6: Forget and reconnect

- If the headphones appear as paired but will not connect, tap the settings icon beside their name.
- Select **Forget Device** or **Unpair**.
- Put the headphones back into pairing mode and pair them again.

Step 7: Restart both devices

- Turn Bluetooth off and on again.
- Restart the phone and power-cycle the headphones.
- Attempt the connection once more.

Step 8: Verify the connection

- Check that the headphones show **Connected** in Bluetooth settings.
- Play an audio file and confirm that sound comes through the headphones.
- Check the phone's audio output selector and headphone volume if necessary.

Result

The headphones should connect successfully, and audio should play through them. If the problem continues, check for software updates or consult the headphone manufacturer's troubleshooting instructions.

Task 3 : A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Steps to solve the problem:

1. Check the USB Connection: Disconnect the webcam and connect it again. Try another USB port to check whether it works.

2. Check Device Manager: Right-click the Start button and open Device Manager. Check under Cameras to see whether the webcam is listed.

3. Check Camera Privacy Settings: Open Settings → Privacy → Camera. Make sure camera access is turned on.

4. Check App Permissions: In Camera settings, allow apps and desktop apps to access the camera, if these options are available.

5. Check Zoom Settings: Open Zoom Settings and select Video. Choose your external webcam from the camera list and check the video preview.

6. Restart the Computer: Close Zoom and restart the computer. If the webcam still does not work, update its driver in Device Manager.

Task 4 : You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Fixing a Printer Showing Offline

Problem: The printer shows “Offline” on the computer.

Steps to Use Windows Troubleshooter

1. Open Settings: Click the Start button and open Settings.

2. Open Troubleshooter: Go to Update & Security → Troubleshoot → Additional troubleshooters.

3. Select Printer: Click Printer and select Run the troubleshooter.

4. Check the Problem: Windows checks for common printer problems, such as connection issues, incorrect settings, and driver problems.

5. Apply the Fix: Windows shows the detected problems and may suggest or automatically apply solutions. Follow the instructions on the screen.

6. Test the Printer: After troubleshooting, check whether the printer shows “Online.” Print a test page to confirm that it works.