Day 4 : Connecting and Testing peripherals Practical

Task 1 : Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.

Procedure

1. Connect the Webcam: Plug the USB webcam into an available USB port on the computer.

2. Install the Driver: Windows may install the driver automatically. If the webcam does not work, download the correct driver from the manufacturer's official website.

3. Check Device Manager: Open Device Manager and expand Cameras. Check whether your webcam is listed.

4. Open the Camera App: Click the Start button, search for Camera, and open the app.

5. Test the Webcam: Check whether the webcam shows your live video. If it does not, check the camera permissions in Windows Settings.

6. Capture a Photo: Click the photo button in the Camera app. Open the saved photo to confirm that the webcam is working.

Result

The USB webcam is connected, the required driver is installed, and the webcam is tested by capturing a photo.

Task 2 : Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.

Procedure

1. Connect the Printer: Connect the printer to the computer using a USB cable or connect it to the same Wi-Fi network as the computer.

2. Install the Driver: Turn on the printer. Windows may install the driver automatically. If required, download the correct driver from the printer manufacturer's official website.

3. Add the Printer: Open Settings → Devices → Printers & scanners. Click Add a printer or scanner and select your printer.

4. Check the Printer: Make sure the printer is listed and ready to use. Check that paper is loaded and ink or toner is available.

5. Print a Test Page: Open Control Panel → Devices and Printers. Right-click your printer, select Printer properties, and click Print Test Page.

6. Verify the Result: Check whether the test page prints correctly. If it prints successfully, the printer is working properly.

Result

The printer is connected to the computer, the correct driver is installed, and a test page is printed to check that the printer works correctly.

Task 3 : Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem.

Procedure

1. Disconnect the Printer: Unplug the printer's USB cable from the computer to create a connection problem.

2. Open Device Manager: Right-click the Start button and select Device Manager.

3. Check for Errors: Look under Printers, Print queues, or Universal Serial Bus controllers. Check for a yellow warning icon or an unknown device.

4. Reconnect the Printer: Connect the USB cable again and make sure the printer is switched on.

5. Scan for Hardware Changes: In Device Manager, click Action → Scan for hardware changes. Windows will search for the connected printer.

6. Check the Result: If the printer appears, check whether it works. If it is still not detected, try another USB port or check the printer driver.

Result

The printer connection problem is checked using Device Manager. Reconnecting the USB cable and scanning for hardware changes can help Windows detect the printer again.

Task 4 : A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications.

Procedure

1. Close Other Apps: Close the Windows Camera app and any other apps using the webcam.

2. Check Zoom Settings: Open Zoom, go to Settings → Video, and select the correct webcam.

3. Check Camera Permissions: Open Settings → Privacy → Camera in Windows. Make sure camera access and desktop app access are turned on.

4. Restart Zoom: Close Zoom completely and open it again. Start a meeting and check the video.

5. Reconnect the Webcam: If the video still does not appear, unplug the webcam and connect it again. Make sure the USB cable is connected propersly.

6. Test the Webcam Again: Open Zoom's video settings and check whether the webcam displays live video. If the problem continues, restart the computer.

Result

The webcam problem is checked by closing other apps, checking permissions, and selecting the correct camera in Zoom. These steps can help the webcam work properly in both applications.