

TESTS

• RED TEST

POSSIBLE INDUCED VOLTAGE,
USE WIBU CORD TO TRY AND BLEED OFF.
ONE END ON 5" OR LONGER SCREWDRIVER
INTO THE GROUND. OTHER END ~~ATTACH~~ TO
THE KNOB ON THE CAP (2 FINGERS ON 188A
AND 2 ON THE CAP) - RETEST. IF GREEN OK
IF RED INFORM MANAGER.

• DC TEST

INITIAL DC TEST WITH GLOVES ON.

TOUCH FIRST THEN DEPRESS TRIGGER
IF RED RELEASE TRIGGER AND RETEST

PLACE SMALL CLIP OF B TEMPORARY BOND
ON 188A ~~TEST CLIP~~ DC GROUND POST AND
BIG CLIP TO KNOWN GOOD GROUND

IF STILL RED MAKE SAFE AND NOTIFY
MANAGER. IF GREEN RETEST ~~WITHOUT~~
~~GLOVES~~. BARE HANDED.