

COMPOUNDS

STERINE - A flux and cleaner used for wiping lead to lead. Helps solder to flow. Looks like a white candle.

PARAFFIN - Hot wax formerly used to waterproof paper and pulp splices. It is very flammable and never use a torch to melt. Use a blower hose to melt.

B - SEALANT - Silicone used to waterproof drop entrance tubes and fiber closures.

DUCT SEAL - Red fire retardant, Grey C/O and Green putty used outside for plugging ducts and manhole covers.

EXPANDABLE FOAM - Non Re-enterable, used for sealing ducts. Expands 15 times its original base.

J UNIVERSAL PLUGGING COMPOUND - Non Re-enterable, comes in a two part mix, used for making plugs.

D ENCAPSULANT - Re-enterable, used in buried splices and fiber splices. A 2 part mix, comes in small cans or large pails.

LEPEC - LEad Particle Entrapment Compound, used to capture lead dust when carding and scraping lead. It is actually shaving cream.

B DESICCANT - Loose granular, like salt, used on paper and pulp splices as a drying agent. Comes in silver bags, use 100 grams for every 600 pairs. Never use with PIC, or 710 modules. One bag has 325 grams.

C DESICCANT - Comes in dust proof bags. Stored in a can (paint can) and it has a moisture indicating capsule inside on the cover, if it is Blue it is OK and if it is Pink it has been affected. Used with PIC, 710 modules and T Carrier apparatus cases. One bag for every 600 pairs,

D DESICCANT - Pelletized used in air dryers to remove moisture

C CEMENT - Liquid rubber used for strength and waterproofing. comes in a silver can with applying brush. Used on IP's, Auxiliary sleeves and wrap joints. Wait until it becomes tacky before putting tapes over C Cement,

E PRESSURE SOLUTION - Soapy water used for testing air leaks, Spray solution on closures under air pressure and look for bubbles/leaks.

PIPE TIGHT - Sealant used on fittings/plugs, except on tank regulators.

D GEL - Solvent used for removing gels in Icky PIC and fiber cables,