

Flash Guard - Makes user look 36" further away electronically

- 3 Rings protect from arcing DC current
- Manufactures name imprinted on back of it

Thumb Stop - If not present or damaged - **YOU DO NOT USE IT!**

- Little piece of plastic that keeps thumb from going/slipping forward past flash guard.
- If your thumb goes forward past resistance field it will leave you open for a hit.
- You might not press trigger all the way and you will not get reading.

Magnetic Locking Switch -

- **Magnetic** - NO metal contact between you and the object you are testing.
- Two conductors separated by an insulator, a capacitive circuit.
- **Locking** - Locking so it will hold reading if you are reaching towards an object and you cannot see "out of sight readings".
- As long as you hold switch it will hold reading

Sticker COLOR CODE for the stickers indicates the last digit of the year tested:

- The sticker has date it that it was last tested with 1188A test set.

Label

- | | |
|---------------------|---|
| Instructions | - Tells how to use 188A, we should know these. |
| Serial # | - The serial number of 188A is recorded when assigned to you. |

Clip

- Used to clip onto climbing belt to carry aloft.
- Color identifies manufacturer -(inner housing same as clip)
 - GOLD** - Communications Technology Co. (also stamped on back of flash guard)
The 188A made by CTC also has a little plastic line on the bottom and top halves of unit to prevent over tightening or under tightening unit.
 - SILVER** - Western Electric

Testing AC 50-20,000 Voltage range

- Always barehanded
- Perform self check on 188A
- If AC voltage range exceeds 20,000v test first test with rubber gloves , then barehanded.
- Approach object, press trigger first before touching object. if Green light OK, if RED light, release trigger then re-test, if still RED; possible hazardous conditions; check for induced voltage. **Hazardous DC Voltage May Still Be Present!!!!!! Even if Green**

INDUCED VOLTAGE - AC - Any voltage induced on the body of the user through electrostatic coupling from power transmission lines is effectively in series with the voltage being tested and may cause the test set to indicate an unsafe condition when none actually exists. Your chances of coming into contact with induced voltage in a bucket truck is greater because you are not grounded.

- Use **W1BU** cord, which is 25' long when stretched, to draw off induced voltage.
- **W1BU** Cord must be inspected/tested prior to use
- Check Carbon Impregnated Cap with by doing a self check & place over end of 188A clip.
- Connect **W1BU** Cord to an old screwdriver 5" or longer and place into the ground and the other end to the knob on the carbon impregnated cap.
- Have two fingers on the cap and two on 188A when testing.
- If GREEN it is ok, if RED, hazard present , descend pole - do second induced voltage test