

SECOND INDUCED VOLTAGE TEST - AC

- Attach 2nd WIBU to tip of 188A (MUST BE NEW STYLE WITH GROOVED TIP)
- Other end of WIBU goes to positive lead of AC meter
- Attach negative lead of AC meter to a 2nd 5" screwdriver placed in ground
- Have 2nd technician read meter WITHOUT TOUCHING IT!! as you retest for induced voltage
- If reading is under 50v OK - over 50v Put gloves on descend pole and make area safe.

DC VOLTAGE

Testing 6- 2,000 Voltage range

- Testing for DC at power rooms, substations, railroads, old factories machine shops, elevator shafts, hospitals and C/O's
- **Initial DC Voltage Test With Gloves On**
- Check & Test 188A , Rubber Gloves and B Temporary Bond before using.
- With Rubber Gloves On connect B Bond small clip to 188A
DC Ground Post and the big clip to a known good ground after testing ground.
- Go towards object, **touch first then press trigger** , if red release trigger and retest . If RED, make safe and notify.
- **Make sure you let go of trigger before pulling 188A off of the object that you are testing.**
You do not want to draw an arc.
- If initial DC test is **SAFE** re-check with 188A barehanded

193A TEST PLUG - This set is used to provide the proper voltage for performing a threshold (sensitivity) test, verifying the proper operation of the 188A Test Set. The 193A consists of an AC Plug, which contains a current limiting voltage divider circuit (301 k ohms) and a test contact. When inserted into a 120V AC outlet, this test set provides a current-limited voltage of approximately 60V AC at 1/4 watt. The voltage is of such value that the current is limited below the threshold of feeling; therefore the test contact is safe if touched.

B TEMPORARY BOND It is a safety item, tested upon receipt, before and after each use. Check the clips, making sure they are secure and visually look for rips, cuts and tears in cord as well as check the continuity of the B BOND with the 188A or KS 8455 Brown Meter prior to use.

- Used when testing for DC VOLTAGE
- **A CAPACITIVE coupling to ground** -used to ground objects that may become energized.
- **BOND** Light fixtures, strands, fences, foreign plant
- Two Mueller Clips #24A - 25 Amp small clip and a #11A - 100 Amp for the larger clip w/ copper clip inside
- Placed with rubber gloves on after testing 188A, Gloves and B Bond
- **FIRST - SMALL CLIP TO A GOOD GROUND SECOND - LARGE CLIP TO OBJECT.**
- If cord smokes or smells, put rubber gloves on, descend pole, make area safe and notify.
- If you find one on something, call test board for any reports/info.
- No reports, check object with 188A, place your B Bond on with your gloves and remove B Bond, cut in half , return to foreman.

WIBU CORD It is a safety item, tested upon receipt, before and after each use.

- Used to remove voltage induced upon the body of user thru static discharge.
- Check the clips, making sure they are secure and **look or feel** for rips, cuts and tears
- Use WIBU cord is 25' long when stretched , you can put two to four cords together.
- WIBU Cord must be checked prior to use w/ 188A for continuity.
- Check Carbon Impregnated Cap with check contact to carbide tip method.