

**** SPIEL IN ORDER EXPECTED AT EXAM ****

RUBBER GLOVES

Safety item, tested upon receipt, before and after each use, weekly & monthly signing off on 6A card with foreman

REMOVE CONTENTS OF BAG - NOTE IF STORED PROPERLY - LAY GLOVES OUT THEN BEGIN TESTS. REMOVE ANY JEWELRY OR WATCHES

1) BAG (At Exam Select zip- top bag! Velcro and side zip NFG)

Stored in insulated bag, duck cotton outer and polyethylene inner
Velcro bag doesn't provide necessary dead air space
The storage bag protects it from moisture, ozone gases/pollution
There is a square cut out of the bottom of the plastic liner to allow moisture to drip out.
Three pairs of gloves used together cotton liners, rubber gloves and leather gloves
Remove gloves from bag carefully as not to catch zipper, fold over top of bag so zipper cannot catch and rip gloves

2) Cotton Liners (At Exam- Dark gauntlet NOT Approved material)

Protect rubber gloves from your perspiration, worn inside rubber gloves
Inspect for loose stitching, tears or rips, imbedded objects
Put liners on one at a time and feel around w/ other hand (bare) checking glove for defects
Gauntlet is laminated with polyvinyl chloride

3) Leather Gloves (Check for cut at Gauntlet at exam)

Protects rubber gloves from creosote, splinters and wear, worn outside rubber gloves
Inspect for tears, rips, loose stitching, creosote, splinters and imbedded objects
Put leather gloves and feel around with other (bare) hand checking glove for defects
You MUST CUT OFF ANY BUCKLES

4) Rubber Gloves SAME OR 1 SIZE SMALLER THAN LEATHERS

Offer ONLY electrical protection
1" per class of glove longer than leathers (class 2 = 2" longer) this prevents the leather from conducting electrical hazards to us
Check gauntlet dam for damage

We use the F type glove - Yellow Tag Stamped Class 2 Type 1 & F Embossed on thumb side

F - Protects up to 34,500 Volts AC phase to phase (conductor to conductor)

Protects up to 20,000 Volts AC phase to ground (conductor to grounded object)

OSHA Limits Class 2 Type 1 gloves to 17,000 Maximum Exposure Phase to Ground

Used for Driving Ground Rods.

Used when Placing and Removing B Temporary bonds or permanent grounds

Used in STORM CONDITIONS

Used for 188A Initial Test For DC Voltage.

Use when you suspect any high voltage (power/sub stations, trolley sta.)

Used when Burning with the Breakdown Set.

Put gloves on properly, state if their useable then store in proper order