

RUBBER GLOVES

SAFETY ITEM , tested upon receipt, before and after each use, weekly and monthly signing off with foreman on 6A card

Used for Driving Ground Rods.

Used when Placing and Removing B Temporary bonds

Used in STORM CONDITIONS

Used for 188A Initial Test For DC Voltage.

Use when you suspect any high voltage (power/sub stations, trolley sta.)

Used when Burning with the Breakdown Set.

Types

Class 1 Type 1 Tag is White D - CO use only N/A

E - Protects up to 15,000 Volts AC phase to phase

Protects up to 8,700 Volts AC phase to ground

Class 2 Type 1 Tag is Yellow F - Protects up to 34,500 Volts AC phase to phase

Protects up to 20,000 Volts AC phase to ground

Phase to Phase is wire to wire without touching ground.

Phase to Ground is one hand on wire and the other to Ground.

WE USE TYPE "F" Identified in three ways:

- 1) The Yellow Tag**
- 2) It Is Written Class 2 Type 1**
- 3) An "F" is Embossed On Glove (at thumb side)**

REMOVE CONTENTS OF BAG - NOTE IF STORED PROPERLY - LAY GLOVES OUT THEN BEGIN TESTS. REMOVE ANY JEWELRY OR WATCHES

1) B -BAG (At Exam Select zip- top bag! Velcro and side zip NFG)

Stored in insulated bag, duck cotton outer and polyethylene inner

Velcro bag doesn't provide necessary dead air space

The storage bag protects it from moisture, ozone gases/pollution

There is a square cut out of the bottom of the plastic liner in the canvas bag to allow moisture to drip out.

Three pairs of gloves used together cotton liners, rubber gloves and leather gloves

Remove gloves from bag carefully as not to catch zipper, fold over top of bag so zipper cannot catch and rip gloves

2) C - Cotton Liners (At Exam- Dark gauntlet NOT Approved material)

Protect rubber gloves from your perspiration, worn inside rubber gloves

Inspect for loose stitching, tears or rips, imbedded objects

Put liners on one at a time and feel around with other hand (bare) checking glove for defects

Gauntlet is laminated with polyvinyl chloride