

WORK AREA PREPARATION

Work Area Prep is to protect you, the public and Bell Atlantic property. Your truck should be equipped with at least 10 cones, one metal men working sign, flags, masts and barrier tape.

DRIVE BY JOB TO SURVEY CONDITIONS

TRAFFIC - How much, how fast, speed limits.

TIME OF DAY - Night/Day, Light/Darkness, RUSH HOUR

WEATHER - Rain, snow, icy, freezing and drivers visibility.

ROAD CONFIGURATIONS - Hills, curves

LOCAL LAWS - Police detail for public and your protection.

Do not use your truck as a shield, park beyond manhole, same direction as traffic. Never face traffic in oncoming lane with truck. you want to be able to see traffic when coming entering and exiting the manhole.

Place MEN WORKING sign with a cone. from work location 10x the speed limit 35MPH and over and 7X the speed limit 30 MPH and under. Then place cones between the sign and the truck 1X the speed limit. Example: 35 MPH - the sign would be 350' ft. back and cones every 35' ft. between sign and truck. Place some cones beyond the truck to guide the traffic.

HILLS AND CURVES: Put an additional sign for opposite direction on other side of curve or hill, due to the blind spot. Place a mast and flags at your location when working on a hill.