Lesson: Practice Exercise

Practice: Export an STL file.

Learning Objectives:
- Export an STL.

Step 1: Export a file for 3D printing

1. Upload and open the file L10-PE-01.f3d.	
2. Right click on Body 1 in the browser and select Save As STL.	
3. Adjust the resolution settings making note of the on screen preview and file size. Save the STL locally.	