

## **Lesson: Create rigid groups**

In this lesson, you will group the individual components together.

## **Learning Objectives:**

- · Apply a rigid joint.
- Create a rigid group.

## **Step 1: Create the rigid group.**

 Carry on with the file from the previous example. Right click on the Lamp Arm and select Unground. Right click on the Ball Joint Socket and select Unground.



2. Select Assemble> Rigid Group to display the properties panel. Select the Lamp Base, Lamp Arm, and the Ball Joint Socket. Click OK. In the Browser, rename the Rigid Group as, "RigidBase".



3. Investigate the history of the file in the Timeline at the bottom of the screen. You can roll back the timeline to a previous state if needed. Save the file.

