



Corporate Client Portal Manual

Client Admin & Corporate Sub-User

Enterprise PecoDrop and assigned Smart Recycling fleet operations

CORPORATE CLIENT USE

Manufactured and operated by ISP Environmental Solutions Pvt. Ltd.

Edition 2026 • Web Dashboard

1. Your portal and access scope

The Corporate Client Portal gives an organization a protected view of its assigned PecoDrop and RVM fleet, recycler/employee activity, rewards, environmental impact and reports. Data from other organizations is not available.

Client Admin
Organization lead. Can view the organization’s fleet and data, manage digital signage and create Corporate Sub-Users with selected machine access.

Corporate Sub-User
Branch, floor or site operator. Can view only explicitly assigned machines and related activity; cannot manage sub-users, security or signage.

Module	Client Admin	Corporate Sub-User
Overview, Machines, Recycler Activity	Yes—own organization	Yes—assigned machines
Rewards, ESG and Reports	Yes	Yes—assigned scope
Digital Signage	Yes	No
Access & Security / Sub-Users	Yes—own organization	No
Enterprise Accounts, raw tables, DB tools/backups	No	No

Scope protection: If a machine, person or site belonging to another organization appears, stop work, take a screenshot without unnecessary personal data, log out and report it to ISP immediately.

2. Login and navigation

1. Open the ISP portal URL supplied by your authorized administrator.
2. Sign in with your individual account. Do not share credentials.
3. Verify your company name/logo and role in the header.
4. If available, choose a station/machine filter. Sub-users will see only their delegated fleet.
5. Use Logout when finished.

Corporate Portal — company identity • station filter • theme • logout

Executive Overview

Machine Health & Operations

Recycler Activity

Rewards & Leaderboards

ESG & Carbon Impact

Analytics & Reports

Your organization / assigned fleet

Machines
online status

Recycling
material total

Impact
CO₂/ESG

All cards, charts and exports follow your permitted organization and machine scope.

Navigation reference

Area	Use
Executive Overview	Headline machine, recycling, user and impact indicators.
Machine Health & Operations	Connectivity, status and alerts for permitted machines.
Recycler Activity	Permitted employee/citizen sessions and point/redemption history.
Rewards & Leaderboards	Rankings, points and reward liability within scope.
ESG & Carbon Impact	Environmental indicators and targets.
Analytics & Reports	Filtered operational and ESG reports/exports.

3. Dashboard and machine monitoring

Daily review

- 1. Open Executive Overview and confirm selected date/site scope.
- 2. Review online/offline machines, recent sessions, material totals and alerts.
- 3. Open Machine Health & Operations for any warning.
- 4. Record machine ID, installed location, last heartbeat, message and time.
- 5. Follow your approved site technician procedure or escalate to ISP.

Machine type	Expected operational data
Enterprise PecoDrop	Corporate employee/department context; plastic, metal/cans and paper weight. Physical kiosk has dual displays, QR scanner/keypad, circle plastic, triangle cans and square paper apertures.
Public RVM assigned to client	Plastic, cans, UBC and reject counts; public user and reward workflow.

Alert response

Condition	Client action
Offline / stale heartbeat	Confirm site power/network and record the last-seen time; do not edit ownership or raw records.
Bin full	Follow the approved machine bin-service guide, then confirm the warning clears.
Repeated rejects or sensor fault	Stop public/employee use if unsafe, preserve evidence and contact the trained technician/ISP.
Incorrect statistics	Check date, site and machine filters; report discrepancy with session/machine references.

Portal limits: The dashboard monitors and manages permitted business functions; it does not authorize opening electrical panels, bypassing safety devices or changing firmware.

4. Client Admin: corporate sub-users

This section applies to Client Admins. Corporate Sub-Users do not have user-management access.

Create a sub-user

1. Open **Access & Security (RBAC)**.
2. Select Add/Create Sub-User.
3. Enter the person's official name, unique username and approved contact details.
4. Select only the machines/sites required for their work.
5. Review the assignment, save, and provide initial credentials securely.
6. Ask the user to sign in and confirm the correct fleet is visible.

Change or revoke access

1. Open the user record and compare current machine access with the approved request.
2. Add/remove only the necessary machines, then save.
3. For leavers or compromised accounts, revoke/suspend access immediately.
4. Confirm the user can no longer reach removed machines or restricted functions.

Least privilege: Never assign every machine for convenience. Access must follow branch, floor, site or job responsibility and should be reviewed periodically.

Quarterly access review

☐	Every account belongs to an active employee/contractor.
☐	Role and assigned machines match current duties.
☐	Dormant, shared and duplicate accounts are removed or escalated.
☐	Departed personnel have no access.
☐	Review evidence is retained according to company policy.

5. Recycler activity, rewards and privacy

Review activity

1. Open Recycler Activity and select the correct date/site/machine scope.
2. Search only when there is an authorized operational or support reason.
3. Compare recycling sessions, earned points, redeemed points and available balance.
4. Use the redemption history to confirm item, points, code/status and timestamp.

Leaderboard and reward review

- Use Rewards & Leaderboards to understand participation and recognize contributors.
- Confirm filters before presenting department or site comparisons.
- Treat estimated voucher liability as a reporting value, not proof that an external merchant paid or accepted a voucher.
- Refer balance, duplicate redemption or payout disputes to the authorized ISP/client administrator.


Voucher note: Vouch365-labelled functions currently include a promotion link and locally recorded voucher references. Do not promise external Vouch365 fulfilment unless ISP confirms that a real provider transaction was completed.

Privacy rules

- Access personal information only for a legitimate business purpose.
- Do not publish employee names, mobile numbers, email addresses or voucher codes in public leaderboards.
- Minimize exported personal data and store reports in approved corporate locations.
- Report suspected cross-tenant visibility or data leakage immediately.

6. ESG impact and reporting

Create a reliable report



- 1. Open ESG & Carbon Impact or Analytics & Reports.
- 2. Set the reporting period and verify your organization/site filters.
- 3. Review total material, item count, sessions, points, CO₂ savings and other displayed ESG indicators.
- 4. Compare unusual changes with machine uptime and site events.
- 5. Export the report and label it with scope, period, generation date and responsible reviewer.

Interpretation rules

Metric	Check before use
Material weight/count	Machine type, active period, accepted vs rejected material and duplicate sessions.
Participation	Unique users vs total sessions and whether anonymous/public sessions are included.
Points/reward value	Earned vs redeemed points, conversion rule and outstanding liability.
CO ₂ /environmental impact	Methodology and conversion factors used by the portal; label estimates appropriately.

Management reporting: Use the portal as the operational evidence source, then apply your organization’s ESG assurance and approval process before external publication.

7. Client Admin: digital signage

Digital Signage is available to Client Admins, not Corporate Sub-Users.

- 1. Open Digital Signage and review existing campaigns.
- 2. Create a campaign with a clear name, approved start/end schedule and audience.
- 3. Upload authorized media in the required format and orientation.
- 4. Select only your organization’s intended kiosk destinations.
- 5. Save, push/publish and verify synchronization at the physical displays.
- 6. Expire/remove old campaigns when no longer approved.

Publishing checklist

☐	Brand, legal, HR and copyright approval obtained.
☐	No confidential, misleading or inappropriate content.
☐	Correct PecoDrop/RVM display orientation and readable resolution.
☐	Correct machines/sites selected.
☐	Start/end time and timezone verified.
☐	Physical kiosk playback confirmed.

Do not upload credentials, QR secrets, personal records or internal-only documents as signage media.

Failed campaign

Record campaign name, machine ID, scheduled time and portal status. Confirm the kiosk is online. Retry publishing once if authorized; if it still fails, preserve the evidence and contact ISP rather than repeatedly uploading duplicate campaigns.

8. Troubleshooting and support

Problem	Action
Cannot sign in	Check username, keyboard state and network; use the approved password/account recovery contact. Do not share passwords.
Expected machine missing	Clear filters, confirm with Client Admin, then provide ISP the machine ID and installation location.
Wrong company or unauthorized machine visible	Stop, capture minimal evidence, log out and report as a security incident.
Dashboard totals appear wrong	Verify date/site filters, compare sessions and note exact cards/charts affected.
Export fails	Reduce date range, confirm browser downloads and retry once; report the module/filter set.
Campaign does not reach kiosk	Confirm schedule, destination and machine online state; escalate after one retry.

Support information

☐	Company, site, machine ID and your portal role.
☐	Date/time and affected module.
☐	Exact message and screenshot with personal data minimized.
☐	Selected date/client/site filters.
☐	Steps already attempted and whether the problem repeats.


Client handover record

Date/time		User	
Company/site		Machine(s)	
Issue/action			
ISP reference			

Safe operating rule: If a function is not visible, it is probably outside your assigned role. Do not attempt to bypass portal permissions; contact your Client Admin or ISP.

Visual Guide 1 — Secure login

Actual portal capture



The login screen features a dark green background with a subtle pattern of leaves and a central white login card. The card contains the ISP logo, the text 'ISP Environmental Solutions SMART RECYCLING PORTAL', and input fields for 'USERNAME OR EMAIL' and 'PASSWORD'. It also includes a 'Remember me' checkbox, a 'Forgot password?' link, a yellow 'SIGN IN' button, and a footer note 'Authorized Administrative Personnel Only'.

ISP Environmental Solutions
SMART RECYCLING PORTAL

USERNAME OR EMAIL
Enter your username or email

PASSWORD
Enter your password

☒ Remember me [Forgot password?](#)

[SIGN IN](#)

Authorized Administrative Personnel Only

Use your individual corporate account and log out on shared devices.

Account
Use issued identity.

Password
Never share it.

Identity
Confirm company and role.

Visual Guide 2 — Corporate overview

Role-restricted workspace

SCOPE: ISP Environmental Master...

21:49:42

ISP

Master Developer (onenet)
SUPER ADMIN

Sign Out

MASTER CUMULATIVE OVERVIEW • 0% Network Online (0 of 3 Kiosks Active)

Machine Operation Overview

Real-time telemetrics across Smart AI Kiosks, PecoDrop stations, and Legacy pulse units.

Refresh Metrics

Export ESG / CSR

DATE RANGE

Last 30 Days (Standard)

MACHINE MODEL

All Models (Master Cumulative)

CLIENT ORG

All Client Organizations

LOCATION

All Locations (Nationwide)

Master Cumulative

All Machines

Smart RVM

PecoDrop (Corporate Kiosk)

Legacy RVM (Counter Units)

Filter Active: 30D • ALL

TOTAL WASTE COLLECTED

TOTAL ITEMS RECYCLED

CLEAN AIR & CO₂ SAVED

POINTS & REWARD VALUE

RECYCLING SESSIONS

Date

Select period.

Model

Separate RVM/PecoDrop.

Location

Filter branch/site.

The workspace is restricted to your organization and assigned machines.

Visual Guide 3 — Machine health

Assigned fleet

SCOPE: ISP Environmental Master...

21:49:45ISPMaster Developer (onenet)
SUPER ADMINSign Out

HARDWARE MONITORING

Machine Network Telemetry

Refresh Heartbeat

Dispatch Field Tech

Fleet GPS Map

ON

CONNECTED MACHINES

3

deployed units

0 Smart RVM • 2 PecoDrop • 1 Legacy

ONLINE & ACTIVE

0

Synced

Awaiting network heartbeat

AWAITING HEARTBEAT

3

units

Field standby or local network offline

MAINTENANCE FLAGS

3

Needs Attention

Hopper bins >85% full or sensor alerts

All Machines (3)

Smart RVM (0)

PecoDrop Scale Units (2)

Legacy Units (1)

Action Needed (3)

Sort by: Recent Heartbeat Ping

Record machine ID, location, heartbeat and status before escalation.

Offline

Check site power/network.

Bin full

Follow service guide.

Unsafe

Stop use.

Visual Guide 4 — Recycler activity

Authorized use only

SCOPE: ISP Environmental Master...

21:49:53

ISP

Master Developer (onenet)
SUPER ADMIN

Sign Out

USER MANAGEMENT PORTAL | Mobile Ecosystem Active

Recyclers & App Community

Live directory of verified citizen recyclers, corporate campus members, wallet point balances, and machine activity.

Refresh Directory

Export Recycler List

REGISTERED RECYCLERS

1

accounts

1 Public (RVM) • 0 Corporate

ACTIVE THIS MONTH

0

0% Rate

0 users currently logged in

UNCLAIMED POINTS

0

pts

Voucher Value:

PKR 0

VOUCHERS CASHED IN

0

pts

Reconciled across 0 vouchers

TOTAL ITEMS DEPOSITED

0

items

0 PET • 0 Cans • 0 g Paper

Search by name, masked mobile number, email, or user ID...

All Recyclers (1)

Smart RVM Public (1)

PecoDrop Corporate (0)

Top Green Champions ★ (0)

Client accounts see only permitted organization and machine activity.

Search

Approved support only.

Reconcile

Earned, redeemed, balance.

Privacy

Minimize personal data.

Visual Guide 5 — Rewards

Corporate scope

SCOPE: ISP Environmental Master...

21:49:56

ISP

Master Developer (onenet)
SUPER ADMIN

Sign Out

COMMUNITY GAMIFICATION

Top Recyclers Live Ranks

Green Champions & Recycling Leaderboard

Refresh Rankings

Issue Payout / Voucher

ON

Search by registered citizen name, contact number, or corporate client (e.g. Tariq, Engro, A

All Clients & Citizens

All Time

This Month

Corporate Units

SILVER RECYCLER

0 Sessions

2

No recycler data

No matching activity for this filter

Recycled Volume:

0 Items (PET & Cans)

Earned Points:

0 Pts

ALL-TIME CHAMPION

Gold Tier

1

No recycler data

No matching activity for this filter

Recycled Volume:

0 Bottles Diverted

Cumulative Balance:

0 Pts

BRONZE RECYCLER

0 Sessions

3

No recycler data

No matching activity for this filter

Recycled Volume:

0 Bottles & UBC Cartons

Earned Points:

0 Pts

Treat voucher value as liability until external fulfilment is confirmed.

Filters

Match site and period.

Identity

Protect user details.

Disputes

Escalate exceptions.

Visual Guide 6 — ESG impact

SCOPE: ISP Environmental Master...

21:50:03

ISP

Master Developer (onenet)
SUPER ADMIN

Sign Out

AUDITED ESG REPORTING

ISO 14064 Standard Compliant

Environmental & Carbon Impact Audit

Refresh

Print Audit

Export ESG Audit (PDF)

ON

THIRD-PARTY AUDITED IMPACT LEDGER

0 kg CO₂e Total Carbon Offset

Calculated from 0 kg of raw recyclable materials collected across public Smart RVMS and corporate PecoDrop units, verified under life-cycle emissions reduction standards.

0 TREES EQUIVALENT

0 MILES AVOIDED

0.00 T DIVERTED WASTE

VERIFIED CARBON OFFSET

TREE GROWTH EQUIVALENT

VEHICLE MILES AVOIDED

ORGANIC & FIBER DIVERSION

Validate inputs, period, uptime and methodology before publication.

Basis

Counts/weights vary.

Estimate

Label equivalents.

Approval

Apply ESG assurance.

Visual Guide 7 — Reports

Filtered exports

SCOPE: ISP Environmental Master...

21:50:08

ISP

Master Developer (onenet)
SUPER ADMIN

Sign Out

ANALYTICS & COMPLIANCE HUB

Machine Network Audits

ISP Environmental Solutions

Comprehensive compliance audits, machine reliability uptime, intake material volumes, and financial voucher reconciliation.

Print Audit

Export Audit Report

Customizable Report Query Filters

Live Aggregated Scope

Reset Filters

Timeline Scope

Client Organization

Machine Location / City

Machine Category

Last 30 Days (Standard Audit)

All Clients & Public Spots

Nationwide Machine Network

All Machines (Cumulative)

ISO 14064

Hardware Fleet

Intake Mass

Audit Ledger

State scope, period, timezone, generation date and reviewer.

Scope

Set filters first.

Validate

Compare uptime.

Share

Approved recipients.

Visual Guide 8 — Digital signage

Client Admin only

SCOPE: ISP Environmental Master...

21:49:48

ISP

Master Developer (onenet)
SUPER ADMIN

Sign Out

DIGITAL SIGNAGE HUB

Machine Displays Live Sync

Screen Ad & Video Manager

Sync All Displays

Upload New Video Ad

AD

ACTIVE MEDIA LIBRARY

3 video assets

2 in rotation • 1 targeted single unit

ACTIVE SCREENS

8100% Synced

5 RVM Headers • 3 PecoDrop Screens

SIGNAGE STORAGE

48.2 MB Used

Optimized MP4 video format (H.264)

PLAYBACK MODE

Seamless Loop

Autoplays during standby

Target Display Scope & Machine Filter

Choose which location or individual machine display you want to manage

View All Video Campaigns

Use approved media and only assigned corporate kiosk destinations.

Approval

Brand/legal clearance.

Destination

Correct kiosks.

Playback

Verify display.