Touchless Web Portal System Overview

The PecoDrop Touchless Web Portal provides a complete 100% touchless mobile interface for corporate employees and citizens operating Reverse Vending Machines (RVM). Users scan a dynamic QR code displayed on the kiosk, authenticate via Google SSO or Mobile Number, trigger physical door unlocks, monitor live container telemetry in real-time, and settle earned rewards directly into their Eco Wallet.


■ Touchless 3-Screen Operational Workflow

SCREEN 1: Start Recycling Mode	SCREEN 2: Kiosk Started Active	SCREEN 3: Points Claimed Mode
• QR Code Scan Landing Page • Google SSO & Corporate Auto-Detect • Mobile Phone Number Input • Kiosk Remote Start Trigger Button	• Kiosk Aperture Unlocked Banner • Live Kiosk Progress Card • Live Split Containers & Points • Integrated Finish & Claim Button	• Session Completion Celebration • Eco Wallet Points Credit (+35 PTS) • Available Points Balance Sync • Browser History Cleaning

■■ Key Operational Highlights

• **Zero Physical Contact**: Scanning dynamic QR code opens smartphone portal, bypassing kiosk touchscreen and physical keypad.
• **Live Telemetry Card**: Displays split real-time CONTAINERS and EARNED +PTS with embedded FINISH & CLAIM button.
• **Browser Hygiene & Safety**: window.history.replaceState purges startToken query parameters upon session finish, preventing stale tab re-locks.

■ SCREEN 1: Start Recycling & Touchless QR Authentication Mode



Screen 1 Component & Authentication Breakdown:

1. Kiosk Identification Header:
Displays machine badge REVERSE VENDING MACHINE • PECO-LHR-01 confirming active QR handshake target.

2. Action Title & Urdu Subtitle:
Displays **Start Recycling** (■■■■ ■■■■ ■■■■ ■■■ ■■■■■■■ ■■■■ ■■■■) inviting immediate touchless activation.


3. System Status Badge:
Prominently displays **READY - TOUCHLESS QR ACTIVATION** indicating kiosk is idle and ready to initiate session.

4. Corporate Google SSO Authentication:
1-Tap **Continue with Google /** ■■■■ ■■■■■■ button. Corporate email domains automatically map user to enterprise perks and departments.

5. Mobile Phone Number Option:
Alternative direct phone entry field (e.g. 03214424625) for quick guest or non-SSO authentication.

6. Hardware Start Trigger Button:
Prominent **START KIOSK NOW • ■■■■ ■■■■ ■■■■** green button sends immediate handshake command to unlock hardware apertures.

■ SCREEN 2: Kiosk Started & Live Session Progress Mode



Screen 2 Component & Live Telemetry Breakdown:


1. Authenticated Greeting & Machine Banner:
Displays **Kiosk Started!** with green recycling logo and personalized greeting: *Welcome Aqeel Ur Rehman! Kiosk PECO-LHR-01 is now starting.*

2. Unlocked Hardware Status Banner:
Prominently displays **ACTIVE - INSERT CONTAINERS NOW** green card confirming physical aperture doors (■ Plastic, ■ Can, ■ Paper) are open.

3. Live Kiosk Session Progress Widget:
Features dark emerald card with ● LIVE KIOSK SESSION PROGRESS header, streaming live container intake metrics updated every 1.5 seconds:
• **CONTAINERS**: Live count of deposited items (0 ■)
• **EARNED**: Real-time points calculation (+0 PTS ■)

4. Integrated Remote Session Finish Button:
Embedded directly inside the Live Progress Card: **FINISH & CLAIM POINTS • ■■■■ ■■■■ ■■■■** button for 1-tap remote session settlement.

■ SCREEN 3: Points Claimed & Eco Wallet Settlement Mode



Screen 3 Component & Settlement Breakdown:

1. Session Celebration Header:
Displays celebration icon and confirmation message: *Points Claimed! Session completed successfully!*

2. Earned Points Credit Banner:
Prominently displays earned session reward: **+35 PTS - ADDED TO YOUR ECO WALLET** credited atomically to user balance.

3. Total Eco Wallet Balance Badge:
Updates and displays user total accumulated points balance in real-time (**6,091 pts available**).

4. Browser History Cleaning (replaceState):
Executes window.history.replaceState to automatically strip startToken query parameter from browser address bar, preventing stale tab re-locks upon closing or refreshing.