



Diagram of JP1 and JP2 headers:

- JP1:** A 6-pin header with the following connections:
 - Pin 1: CTS_5V
 - Pin 2: VCC
 - Pin 3: GND
 - Pin 4: TX_5V
 - Pin 5: RX_5V
 - Pin 6: RTS_5V
- JP2:** A 2-pin header with the following connection:
 - Pin 1: PIO4

Rev:
Id: 1/1