







If DTR is LOW, toggling RTS from HIGH to LOW resets to run mode.
If RTS is HIGH, toggling DTR from LOW to HIGH resets to bootloader.



Released under the Creative Commons
Attribution Share-Alike 4.0 License
<https://creativecommons.org/licenses/by-sa/4.0/>

TITLE: \${PROJECTNAME}

REV:
v10

Sheet: \${#}/\${##}

Date: `{CURRENT_DATE}`

Size: User	Date:
KiCad E.D.A.	eeschema 7.0.6

Rev:
Id: 1/1