



POWER SUPPLY


USB Power/Data



JST Battery In




3.3V Reg




ATSAMD21 MICROCONTROLLER


SERCOM 1: internal I2C
SERCOM 3: internal SPI
SERCOM 4: Serial
SERCOM 5: external I2C
ATSAMD21G_QFN




Capacitive Touch/IO Pads




LEDs




Accelerometer




SPI FLASH




Sound Sensor




NeoPixels




Slide Switch




Light Sensor



Temp Sensor



Speaker



CC 2.5 BY-SA

Sheet: \$#{}/\$###

Adafruit Industries

Re: working.kicad_sch

Title:

Size: User Date:

KiCad E.D.A. kicad-cli 7.0.6-7.0.6-ubuntu22.04.1

Rev:

Id: 1/1