




MODULE-POWE **KLD1117-S023-V33D** **oom.lt/MP1117**




MODULE-XTAL **5032-MZ16-01** **oom.lt/MX53M16**




MODULE-CONN **ISP-STAN-SM** **oom.lt/MCISPSM**





MODULE-CONN **I2C-QWIIC-01** **oom.lt/MCQ**



MODULE-MCUU **ATTINY84-S014-01** **oom.lt/MMAT84S**



MODULE-MOSN **K4184-T252-TL** **oom.lt/MMN4184252TL**



Sheet: /
 File: working.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. kicad-cli 7.0.6-7.0.6-ubuntu22.04.1

Rev:

Id: 1/1