



PWM power stage


Load output




Solar current



Load current



Solar and battery voltage



Negative voltage max:
 10V bat - 55V panel = -35V

If not stated otherwise,
 all MLCC 50V X7R

Website: <https://libre.solar>

Author: Martin Jäger

Libre Solar

Sheet: /

File: working.kicad_sch

Title: PWM 2420 LUS

Size: A4 Date: 2019-08-26

KiCad E.D.A. eeschema 7.0.6

Rev: 0.3

Id: 1/1