




RST  Enter Bootloader
Keep "BOOT" bridged
Bridge "RST" for a moment
BOOT  Remove all bridges

Sheet: Bottom copper
File: working.kicad_pcb

Title:

Size: A4	Date: 2023-08-02_17-08-53
KiCad E.D.A. 7.0.6-7.0.6-ubuntu22.04.1 + KiBot v1.6.3	

Rev:
Id: 2/6