SWC1
${TP_SIGNAL_NAME}
Q2
reset
RESET
3.3V
GND
C3
1uF
GND
ATSAMD21E
26
/RESET
9
VDDA
30
VDDIN
29
VDDCORE
GND
28
GNDA
IC3
PA00/EINT0/SERCOM1.0 1
PA01/EINT1/SERCOM1.1 2
PA02/EINT2/AIN0/Y0/VOUT 3 A0
PA03/EINT3/VREFA/AIN1 4 A1
PA04/EINT4/VREFB/AIN4/SERCOM0.0 5 A2
PA05/EINT5/AIN5/SERCOM0.1 6 A3
PA06/EINT6/AIN6/SERCOM0.2 7 TX_A6
PA07/I7/AIN7/SERCOM0.3/I2SD0 8 RX_A7
SERCOM0
JP1
SDA
SCL
PA08/I2C/AIN16/SERCOM0+2.0/I2SD1 11 FLASH_CS
PA09/I2C/I9/AIN17/SERCOM0+2.1/I2SMC 12 MISO
PA10/I10/AIN18/SERCOM0+2.2/I2SCK 13 MOSI
PA11/I11/AIN19/SERCOM0+2.3/I2SF0 14 SCK
SERCOM2
R1
5.1K
3.3V
PA14/I14/SERCOM2+4.2 15
PA15/I15/SERCOM2+4.3 16 NEO_PWR
PA16/I2C/I0/SERCOM1+3.0 17 SDA
PA17/I2C/I1/SERCOM1+3.1 18 SCL
PA18/I2/SERCOM1+3.2 19 NEOPIX
PA19/I3/SERCOM1+3.3/I2SD0 20 MISO2
SERCOM1
PA22/I2C/I6/SERCOM3+5.0 21 MOSI2
PA23/I2C/I7/SERCOM3+5.1/SOF 22 SCK2
PA24/I12/SERCOM3+5.2/D- 23 D-
PA25/I13/SERCOM3+5.3/D+ 24 D+
PA27/I15 25
PA28/I8 27
PA30/I10/SECOM1.2/SWCLK 31 SWCLK
PA31/I11/SECOM1.3/SWDIO 32 SWDIO
SERCOM3
${TP_SIGNAL_NAME}
SWC0
${TP_SIGNAL_NAME}
SWD0
VBUS
+5V
D1
NSR0320
VBUS
D+
D-
CC1
CC2
SBU1
SBU2
GND
USB C
USB TYPE C
X6
VBUS
D+
D-
CC1
CC2
5.1K
R5
R6
5.1K
GND
GND
GND
NEO_PWR
WS2812B
VDD
NEOPIX
DI
GND
DO
GND
MT1
MT2
MT
MT
GND
3.3V
SDA
SCL
GND
SDA
SCL
U2
SCK2
MOSI2
MISO2
FLASH_CS
SCK
MOSI
MISO
SSEL
WP#/IO2
HOLD#/IO3
VCC
VSS
3.3V
3.3V
GND
TP1
+5V
TP2
GND
3.3V
MOSI
MISO
SCK
RX_A7
JP3
+5V
C1
10uF
GND
U1
IN
EN
GND
OUT
P4
AP2112K-3.3
GND
3.3V
C8
10uF
GND
3.3V
C2
1uF
GND
Adafruit QT Py
CC 2.5 BY-SA
http://adafruit.com/products/4600
TITLE: ${PROJECTNAME}
Document Number:
REV:
Sheet: /
File: working.kicad_sch
Date: ${CURRENT_DATE}
Sheet: ${#}/${##}
Title:
Size: User
Date:
Rev:
KiCad E.D.A. kicad-cli 7.0.6-7.0.6~ubuntu22.04.1
Id: 1/1