



C3: Use 1uF to filter high frequency noise, or 10uF if lower frequency noise is present



TP6	A3_EINK_RST	TP13	A7_EINK_DC
TP7	A2	TP12	A6_EINK_CS
TP8	A1	TP11	SDA_MOSI
TP9	A0_SPEAKER	TP10	SCL_SCK



CC 2.5 BY-SA

Sheet: $\$ \{ \# \} / \$ \{ \#\# \}$

Adafruit Industries

File: working.kicad_sch

Rev:

Id: 1/1