

New on v1.3:
SMD Audio Jack
Added labels to pins 3/4
Removed TX connection (not used)
Add jumper to Reset line
Added inline resistors to 3.3V inputs
Corrected Right/Left channels
Reset is now pulled high (non-reset)
Combined Speaker 0.1"

GPIO0 low / GPIO1 high puts VS1053 in MIDI mode

Released under the Creative Commons Attribution Share-Alike 3.0 License
http://creativecommons.org/licenses/by-sa/3.0
Design by: C. Taylor, N. Seidle

TITLE: ${PROJECTNAME}	SFE	SFE
Document Number:		REV: v13
Date: ${CURRENT_DATE}	Sheet: / File: working.kicad_sch	Sheet: ${#}/${##}
	Title:	
	Size: User Date: KiCad E.D.A. eeschema 7.0.6	Rev: Id: 1/1