



LEDs




Power


The Teensy regulates 3.3v up to 100mA




Bridge VIN-EXT_PWR jumper to source Teensy from EXT_PWR. Supply at least 100mA in this mode unless the Teensy's VUSB-VIN jumper has been opened.



XBee




Teensy 3.1



Open to separate AGND from GND

Switches



Released under the Creative Commons

Attribution Share-Alike 4.0 License

<https://creativecommons.org/licenses/by-sa/4.0/>

TITLE: \${PROJECTNAME}

Design by:

REV:

Date: \${CURRENT_DATE}

Sheet: \${#}/\${##}

Size: User

Date:

Rev:

KiCad E.D.A. eeschema 7.0.6

Id: 1/1

sparkfun

open hardware