MNT1 MNT2 MNT3 MNT4

fiducial fid1 | fiducial fid2 | fiducial fid3 | fiducial fid4

uC

+3.3V

C1 100nF | C2 100nF | C3 100nF | C4 100nF | C5 10nF_X7R | C6 1uF_X5R | C7 4.7uF | C8 4.7uF

GND

RESET

BOOT_0

9C-8.000MBBK-T

Y1

C14 10pF | C15 10pF

GND GND

U5V

R7 39k

R8 47k

GND

USR_BTN_2
LED_1
LED_2

SPI1_HOLD
VUSB_ADC

INT1_ADXL
INT2_ADXL
INT_MPU
I2C1_SCL
I2C1_SDA

I2C2_SCL
I2C2_SDA

LED_4
LED_3

VIN

R5 47k

R6 10k

GND

USR_BTN_1
VBAT_ADC
DEBUG_TX_uC
DEBUG_RX_uC
SPI1_CS_1
SPI1_SCK
SPI1_MISO
SPI1_MOSI
SPI1_CS_2
Tx_uC
Rx_uC
CTS_uC
RTS_uC
SWDIO
SWCLK

USB - FT232

U5V

C9 100nF

GND

C10 10nF_X7R | C11 100nF | C13 4.7uF | C12 100nF

GND GND GND GND

Rx_uC
Tx_uC
CTS_uC
RTS_uC

+3.3V

D1 LED | 1k1 R2

D2 LED | 1k1 R3

10k R4

LEDs

+3.3V +3.3V +3.3V +3.3V

D3 LED | D4 LED | D5 LED | D6 LED

1k1 R9 | 1k1 R10 | 1k1 R11 | 1k1 R12

LED_1 | LED_2 | LED_3 | LED_4

Conn

DEBUG_RX_uC
DEBUG_TX_uC

GND

J2 DEBUG

+3.3V

SWCLK
SWDIO
RESET

GND

J3 SWD

+3.3V

BOOT_0

GND

BOOT_JMP J4

ADXL

ADXL345

I2C mode is used
Both voltages are supported (for 3.3 and 5V boards)
SDO needs to be connected to GND
CS needs to be connected to 3.3V, only when it is not internally conected!

J6 GS3

J7 GS2

GND_ADXL
VCC_ADXL
CS_ADXL
INT1_ADXL
INT2_ADXL
SDO_ADXL
SDA_ADXL
SCL_ADXL

I2C2_SDA I2C1_SDA I2C2_SCL I2C1_SCL

MPU

MPU6050

AD0 is pulled down in board
XDA and XDL are not used (no external compass)

VCC_MPU
GND_MPU
SCL_MPU
SDA_MPU

I2C1_SCL
I2C1_SDA

AD0_MPU
INT_MPU

I2C

Pull up resistors just in case that more juice is needed.
Close GS to disable the line.
CHOOSE ONE OF TWO

+3.3V +3.3V

2k2 R16 | 2k2 R17 | 2k2 R18 | 2k2 R19

I2C1_SCL I2C1_SDA | I2C2_SCL I2C2_SDA

J10 GS2 | J13 GS2 | J11 GS2 | J12 GS2

GND GND GND GND

Buttons

+3.3V +3.3V +3.3V

SW_Push_Dual SW1 | 100k R13 | RESET | C16 100nF

SW_Push_Dual SW2 | 100k R14 | USR_BTN_1 | C17 100nF

SW_Push_Dual SW3 | 100k R15 | USR_BTN_2 | C18 100nF

GND GND | GND GND | GND GND

Not in PCB

NM-J16 Battery_conn | NM-R1 47k | NM-R2 4k7 | NM-R3 39k

Power

TO_SOT_Packages_SMD:SOT-223

U3 LD1117S50TR

VIN C19 10uF (25V) | E5V C20 10uF

GND GND

E5V BAT60JFILM D7

U5V BAT60JFILM D9

U4 LD3985M33R_SOT23

+5V

1k1 R20 | D10 LED | C21 1uF_X5R | C22 100nF

+3.3V

C23 10nF_X7R | C24 1uF_X5R | C25 100nF

GND GND GND GND GND GND GND

J18 BAT

SW4 SW_DPDT_x2

SW4 SW_DPDT_x2

GND

VIN

+5V

VIN U5V PWR_FLAG

SPI

+3.3V

23LCRAM

U5

SPI1_HOLD
SPI1_CS_2

SPI1_CS_1
SPI1_SCK
SPI1_MISO
SPI1_MOSI
SPI1_CS_2

SPI1_SCK
SPI1_MOSI
SPI1_MISO

SPI_ANALYZER J17

+3.3V

SPI1_CS_1

SPI1_SCK
SPI1_MOSI
SPI1_MISO

RAM is used to store accelerometer measurements
EEPROM is used to store configurations

PCB Acelerómetro - Mat. Av.
Fernando Cladera

Sheet: /
File: working.kicad_sch

Title:

Size: User	Date: 2017-08-16	**Rev:**
KiCad E.D.A. eeschema 7.0.6		Id: 1/1