







Copyright (©) 2020, T.Schneidermann <tim@tinkerforge.com>

Licensed under CERN OHL v.1.1

Tinkerforge GmbH

Sheet: Bottom copper

File: working.kicad_pcb

Title: Grounding Ring


Size: A4

Date: 2021-02-19

Rev: 1.0

KiCad E.D.A. 7.0.6-7.0.6-ubuntu22.04.1 + KiBot v1.6.3

Id: 2/6



Copyright (©) 2020, T.Schneidermann <tim@tinkerforge.com>

Licensed under CERN OHL v.1.1

Tinkerforge GmbH

Sheet: Bottom courtyard area

File: working.kicad_pcb

Title: Grounding Ring


Size: A4


Date: 2021-02-19

Rev: 1.0

KiCad E.D.A. 7.0.6-7.0.6-ubuntu22.04.1 + KiBot v1.6.3

Id: 3/6





Copyright (©) 2020, T.Schneidermann <tim@tinkerforge.com>

Licensed under CERN OHL v.1.1

Tinkerforge GmbH

Sheet: Bottom documentation

File: working.kicad_pcb

Title: Grounding Ring


Size: A4

Date: 2021-02-19

Rev: 1.0

KiCad E.D.A. 7.0.6-7.0.6-ubuntu22.04.1 + KiBot v1.6.3

Id: 5/6



Copyright Tinkerforge GmbH 2020.
This documentation describes Open Hardware and is licensed under the
CERN OHL v. 1.1.
You may redistribute and modify this documentation under the terms of the
CERN OHL v.1.1. (<http://ohwr.org/cernohl>). This documentation is distributed
WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF
MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A
PARTICULAR PURPOSE. Please see the CERN OHL v.1.1 for applicable
conditions

Copyright (©) 2020, T.Schneidermann <tim@tinkerforge.com>
Licensed under CERN OHL v.1.1

Tinkerforge GmbH

Sheet: Front documentation
File: working.kicad_pcb

Title: Grounding Ring

Size: A4	Date: 2021-02-19	Rev: 1.0
KiCad E.D.A. 7.0.6-7.0.6-ubuntu22.04.1 + KiBot v1.6.3		Id: 6/6